



Metal Cutting Saws Maintenance and Repair Manual

CA-350, CS-350, FA-350 and FS-350 Series Saws

Manual P/N KTS-04
Revised June, 1992

THIS OPERATING MANUAL SHOULD BE READ BY EVERYONE EXPECTED TO OPERATE OR SUPERVISE THE OPERATION OF THIS MACHINE. SPECIAL ATTENTION SHOULD BE FOCUSED ON THE PAGES CONCERNING SAFETY.

For your convenience when ordering parts,
please fill in the following information
when you receive your new KALAMAZOO saw.

MODEL _____

SERIAL NO. _____

KALAMAZOO has been committed to continuous product improvement since 1867. In keeping with this commitment, we reserve the right to change the information in this manual without notice. Every attempt has been made to insure the accuracy of this manual. Even so, KALAMAZOO assumes no responsibility for errors or omissions, nor is any liability assumed for damages resulting from the use of the information contained in this manual.

Kalamazoo Saw * 508 Harrison, Kalamazoo, MI 49007
(616) 345-2141 (MI) [REDACTED] (616) 345-3932 (FAX)

MAINTENANCE AND REPAIR MANUAL
TABLE OF CONTENTS

SECTION 1 - PREVENTATIVE MAINTENANCE

Lubrication Instructions	1.1
Gearbox Lubrication	1.2
Oils and Lubricants	1.2
Air/Oil Reservoir Maintenance	1.3
Electric Motor Maintenance	1.4
Changing Drive Belts	1.4
V-Belt Troubleshooting	1.5
Spray Mist Coolant Maintenance	1.6
Coolant Pump Maintenance	1.7
Gearbox Maintenance	1.8
Barfeed Maintenance	1.8
Vacuum Maintenance	1.9
CA-350/FA-350 Spare Parts	1.11
CS-350/FS-350 Spare Parts	1.12
Cylinder Seal Kits	1.13

SECTION 2 - TROUBLESHOOTING GUIDE

General Troubleshooting	2.1
Semi-Automatic Saws	2.2
Automatic Saws	2.3

SECTION 3 - ILLUSTRATED PARTS DRAWINGS:GENERAL

Tool Kit	3.1
Vise Cylinder Assembly	3.2
Barfeed Assembly	3.3
Length Counter Parts	3.4
Backstop Assembly	3.5
Barfeed Carriage	3.6
Barfeed Carriage Overhead Roller	3.7
Stock Stop Assembly	3.8
Stock Stands	3.9
Roller Tables	3.10
Roller Table Stock Stop	3.11
Fixture Mounting Table Option	3.12
Overhead Clamp Option	3.13
Short Length Stock Stop Option	3.14

MAINTENANCE AND REPAIR MANUAL
TABLE OF CONTENTS
(continued)

SECTION 4 - ILLUSTRATED PARTS DRAWINGS: CA-350/FA-350 SAWS

Base Components: CA-350 & CA-350PV	4.1
Base Components: FA-350 & FA-350PV	4.2
Base Components: FA-350SA	4.3
Base Components: FA-350A	4.4
Bed & Vise Assembly	4.5
Head Components	4.6
Spindle Assembly	4.7
Manual Head Lift Parts	4.8
Powered Head Lift Parts	4.9
Blade Guard Parts	4.10

SECTION 5 - ILLUSTRATED PARTS DRAWINGS: CS-350/FS-350 SAWS

Base Components: CS-350 & CS-350PV	5.1
Base Components: FS-350 & FS-350PV	5.2
Base Components: FS-350SA	5.3
Base Components: FS-350A	5.4
Bed & Vise Assembly	5.5
Coolant Tank Assembly	5.6
Blade Guard Parts	5.7
Blade Brush Parts	5.8
Manual Head Lift Parts	5.9
Powered Head Lift Parts	5.10
Gearbox Assembly: Drive Spindle	5.11
Gearbox Assembly: Worm Shaft	5.12

SECTION 6 - REPLACEMENT INSTRUCTIONS

Squaring the Saw Vise	6.1
Vise Clamping Cylinder	6.2
Vise Screw Retainer	6.3
Blade Drive Spindle (CA & FA Series Saws)	6.4
Blade Drive Motor (CS & FS Series Saws)	6.5
Changing Drive Speeds (CA & FA Series Saws)	6.6
Changing Drive Speeds (CS & FS Series Saws)	6.7
Parts Counter	6.8

SECTION 7 - PNEUMATIC SYSTEM

Head Feed Reservoir Parts	7.1
Carriage Feed Reservoir Parts	7.2
Pneumatic Valve Parts: PV Model Saws	7.3
Pneumatic Valve Parts: SA Model Saws	7.4
Pneumatic Valve Parts: A Model Saws	7.5
Filter/Regulator/Lubricator Parts	7.6
Pneumatic Diagram: PV Model Saws	7.7
Head Lift Fittings	7.8
Pneumatic Diagram: SA Model Saws	7.9
Pneumatic Diagram: A Model Saws	7.10

MAINTENANCE AND REPAIR MANUAL
TABLE OF CONTENTS
(continued)

SECTION 8 - ELECTRICAL SYSTEM

Electrical Controls: 'C' Series Saws	8.1
Switch Panel Assembly: FA-350/PV, FS-350/PV	8.2
Switch Panel Assembly: FA-350SA, FS-350SA	8.3
Console Assembly: FA-350A, FS-350A	8.4
Electrical Enclosure Panel	8.5
Changing Operating Voltage	8.6
Changing Indicator Lamps	8.7
Switch Operator/Contact Block Replacement	8.10
Motor Contactor Maintenance	8.11
Logic Controller Wiring	8.12
Parts Counter Wiring	8.13
Switch Panel Wiring: SA Saws	8.14
Switch Panel Wiring: A Saws	8.15
Electrical Schematic: CA-350/CA-350PV Saws	8.16
Electrical Schematic: CS-350/CS-350PV Saws	8.17
Electrical Schematic: FA-350/FA-350PV Saws	8.18
Electrical Schematic: FS-350/FS-350PV Saws	8.19
Electrical Schematic: FA-350SA Saws	8.20
Electrical Schematic: FS-350SA Saws	8.21
Electrical Schematic: FA-350A Saws	8.22
Electrical Schematic: FS-350A Saws	8.23
Electrical Schematic: Vacuum Chip Removal System	8.24

LUBRICATION POINTS CIRCULAR SAWS




figure 1.1

DAILY:

- * Check the filters on the incoming air. Drain as needed.
- * Clean any chips off the machined surfaces of the saw base and OIL as needed to help head rotation.
- * Make sure all chips are out of the vise area before starting a cut. Chips may prevent proper clamping of the vise and create an unsafe condition.
- * Pull out the plastic plug in the front of the Head Rotation casting and squirt oil into the hole to prevent rusting of the saw bed.
- * Pump oil into both of the flush oiler fittings on the base of the vise support casting. This will help keep the vise pivot shaft from rusting and binding.
- * Oil the round vise ways to help the vise slide in and out. Also oil the vise screw threads.
- * On automatic saws, pump oil into the two flush oilers on the carriage vise as well as onto the carriage vise shafts and screw threads.
- * Make sure any vise screw threads are free of chips.
- * Clean and oil the barfeed carriage shafts on automatic saws.

GEARBOX LUBRICATION

The gearbox oil in CS-350 and FS-350 saws should be drained at the end of two weeks operation, and the gearbox flushed with a light flushing oil. If it is filtered, the drained oil may be re-used; otherwise use new oil. After this first change, the oil should be changed every six months or 2500 operating hours, whichever comes first. Under severe conditions, such as rapidly changing temperatures, damp, or dirty atmospheres, it may be necessary to change the oil every one to three months.

DO NOT allow the gearbox oil to become contaminated with water or dirt. This will contribute to the build-up of sludge in the oil, which will greatly reduce the life of the gearbox.

OILS AND LUBRICANTS

* GEARBOX (CS-350/FS-350 saws): Mobilgear #634 or SHC 634
(5 qts req'd)

* AIR/HYDRAULIC RESERVOIRS: Mobil 'Velocite #10' or equal
(107 SUS @ 100°F)

Head Feed: approx. 1 qt. for both

Carriage Feed: approx. _ qts. for both

* PNEUMATIC LUBRICATOR (saws with power vise): Mobil 'Velocite #10'
(5 ounces)

* OIL: 20W motor oil (as required for lubricating shafts, etc)

AIR/OIL RESERVOIRS

HEAD FEED
RESERVOIRS

REAR OF
CABINET






figure 1.2

CARRIAGE FEED
RESERVOIRS



CUTTING
AREA




figure 1.3

To refill the reservoirs, remove the plugs shown in the top of the reservoirs, and refill to the levels shown. Be sure to tighten the plugs when replacing them. If you are filling the reservoirs with the saw head down, the fill heights should be opposite of what is shown. The reservoirs are filled with Mobil 'Velocite 10' oil, which is available from your local Mobil distributor.

Under normal conditions, there should be no need to drain and flush the reservoirs. If it should become necessary, remove the screws that mount the reservoir subassembly to the base so that the unit can be raised. Remove the drain plugs, and drain as needed.

ELECTRICAL MOTOR MAINTENANCE

LUBRICATION: Most electric motors are greased with a polyurea grease. Examples of this type of grease include Shell 'Dolium R', Chevron 'SRI #2', and Texaco 'Premium RB'. These greases are NOT compatible with lithium-based greases, and should not be mixed.

LUBRICATION INTERVALS:

5000 hours of operation/year (two shifts/day): every 5 years

Continuous Normal Duty: every 2 years

Seasonal Service: (Motor is idle 6 mos.): grease before each season's use

Continuous High Temperature, Dirty, or Damp Conditions:
every 6 months

LUBRICATION PROCEDURE: Overgreasing the bearings can cause premature bearing failure. Clean the tip of the grease fitting and apply 1 or 2 full strokes from a grease gun.

CAUTION: Keep the grease clean. Lubricate the motor at standstill. DO NOT mix petroleum greases with silicone greases.

CHANGING DRIVE BELTS CA-350/FA-350 SAWS




figure 1.4

1. Remove the three screws to the Belt Cover and remove it.
2. Loosen the two motor plate bolts (see illustration) and slide the motor towards the blade until the belts can be removed.
3. The belts are retensioned by pushing the motor away from the blade until a slight thumb pressure on the center of the belts produces a 5/8" deflection and then tightening the motor plate bolts.

Maintenance & Trouble-Shooting Guide

Seven Warning Signs of Short V-Belt Life (Causes and Suggested Corrections)

1 Rapid V-Belt Wear	<ul style="list-style-type: none"> • Rubbing Belt Guard • Check guard clearance 	<ul style="list-style-type: none"> • Worn Sheave Grooves • Check groove sidewalls 	<ul style="list-style-type: none"> • Sheave Diameter Too Small • Redesign drive or use Cog-Belt 	<ul style="list-style-type: none"> • Overloaded Drive • Redesign drive or use Cog-Belt 	<ul style="list-style-type: none"> • Mismatched Belts • Replace with matched set 	<ul style="list-style-type: none"> • V-Belt Slipping • Increase tension or use Cog-Belt
	<ul style="list-style-type: none"> • Improper V-Belt Installation, Belts Pried over Sheaves • Replace belts, do not pry belts over sheaves 	<ul style="list-style-type: none"> • Belts Improperly Stored or in Storage too Long • Use new set of V-Belts 	<ul style="list-style-type: none"> • Replacing one Belt in Multiple Drive • Replace Complete set of V-Belts 	<ul style="list-style-type: none"> • Improperly Designed Drive • Consult local distributor 	<ul style="list-style-type: none"> • Oil or Heat Condition • Use Cog-Belt 	<ul style="list-style-type: none"> • Sheave Misalignment • Correct alignment
2 V-Belts turned Over in Sheave Groove	<ul style="list-style-type: none"> • Broken Cords in V-Belt, Belts Pried over Sheaves • Replace belts, do not pry belts over sheaves 	<ul style="list-style-type: none"> • Overloaded Drive • Redesign drive or use Cog-Belt 	<ul style="list-style-type: none"> • Impulse Loads • Use Vee-Band 	<ul style="list-style-type: none"> • Foreign Material in Grooves • Improve Belt Shield 		
3 V-Belt Slippage	<ul style="list-style-type: none"> • Insufficient Tension • Increase tension 	<ul style="list-style-type: none"> • Overloaded Drive • Redesign drive or use Cog-Belt 	<ul style="list-style-type: none"> • Sheave Worn, Belts Bottoming in Groove, Shiny sheave groove bottom • Replace Sheave 	<ul style="list-style-type: none"> • Oily Drive (Leaking Bearings) • Correct unnecessary oil or grease condition 	<ul style="list-style-type: none"> • Oily Drive Conditions • (Where oil condition cannot be eliminated) • Use Cog-Belt 	
4 V-Belt Squeal	<ul style="list-style-type: none"> • Overloaded Drive • Redesign drive or use Cog-Belt 	<ul style="list-style-type: none"> • Insufficient Arc of Contact • Increase center distance or use Cog-Belt 	<ul style="list-style-type: none"> • Insufficient Tension • Increase tension use gauge 	<ul style="list-style-type: none"> • Belts Bottoming in Grooves • Replace sheave and/or belts 		
5 Checked or Cracked V-Belts	<ul style="list-style-type: none"> • Belt Slippage Causing Heat • Increase belt tension or use Cog-Belt 	<ul style="list-style-type: none"> • Excessive Heat (Ambient) • Provide adequate ventilation or use Cog-Belt 	<ul style="list-style-type: none"> • Sheaves Too Small • Redesign drive use Cog-Belt 	<ul style="list-style-type: none"> • Backside Idler • Use Cog-Belt 		
6 Hot Bearings	<ul style="list-style-type: none"> • Drive Over-Tensioned • Check sheaves for wear-check tension 	<ul style="list-style-type: none"> • Belt Slippage (causing heat) • Increase tension check sheaves 	<ul style="list-style-type: none"> • Sheaves Too Far Away From Bearing • Move sheaves closer to bearing 	<ul style="list-style-type: none"> • Sheaves Too Small • Check NEMA Min. Diameters 	<ul style="list-style-type: none"> • Poor Bearing Condition • Check design & maintenance 	
7 Repeated V-Belt Fracture	<ul style="list-style-type: none"> • Shock Loads • Check Design Use Cog-Belt 	<ul style="list-style-type: none"> • Improper V-Belt Installation, Belts Pried Over Sheaves • Replace belts, do not pry belts over sheaves 	<ul style="list-style-type: none"> • Misplaced Slack • Keep slack on one side when installing 	<ul style="list-style-type: none"> • Foreign Object in Groove • Improve Belt Shield 		

COOLANT SYSTEM MAINTENANCE

SPRAY MIST UNITS

CLEANING: Cleaning the reservoir occasionally will keep the mist unit working properly. The unit can be cleaned as follows:

1. Shut off the air supply to the saw.
2. Separate the cover and the reservoir by removing the screws on both sides of the unit.
3. Wash the reservoir with warm soapy water. This solution can be run through the system to clean the lines and nozzles. Remove the pickup tube assembly by sliding the locking tab and pulling the assembly from the pump. Clean the filter screen with a solvent and blow air through the tube to clean it out.
4. Re-assemble the unit.

NOZZLE REPLACEMENT (CA-350, CA-350PV, FA-350, and FA-350PV saws):

1. Remove the old or damaged nozzle by loosening the knurled nut at the end of the tubing.
2. Slide the black and yellow tubing from the end of the nozzle.
3. Take the new nozzle and slip the yellow tubing onto the shorter brass tube.
4. Slide the black tubing over the nozzle body and lock it in place by retightening the knurled nut over the black tubing.

NOZZLE TIP REPLACEMENT (FA-350SA and FA-350A saws):

1. Bend the nozzle sharply to snap the tip from the segmented casing.
2. Pull the tube from the barb inside the nozzle tip. DO NOT allow the tube to slip back into the casing.
3. Take the new tip and push the tube completely over the barb.
4. Snap the tip onto the casing.


COOLANT PUMP MAINTENANCE (Flood Coolant Systems)

CAUTION: DISCONNECT THE POWER BEFORE ATTEMPTING TO SERVICE OR REPLACE ANY COMPONENT!

1. This unit is self-lubricating. Oiling is not required.
2. Periodic cleaning of the pump parts will prolong the life and efficiency of the pump. Refer to the drawing below for the assembly and disassembly of the pumping head.
3. Lightly clean any corrosion or debris which may clog the impeller. Use a brush and penetrating oil and lightly scrape. NOTE: Do not allow sediment to build up to within 2" of the pump.
4. Turn the impeller by hand to make sure it is free. Turn on the power to see if the impeller will turn. If it does, replace the front, and the pump should operate as good as new.

PUMP TROUBLESHOOTING

1. Should the pump fail to operate, check the following:
 - a) Power supply and connections
 - b) Is the pump below the coolant level in the tank?
 - c) Is air trapped in the pump head?
 - d) Is there sediment build-up over the pump inlet?
2. An Air lock or bubble will prevent the pump from pumping. Trapped air can usually be removed by:
 - a) Turning the pump off and re-starting
 - b) Make sure the discharge line is sloping upward to prevent the formation of air pockets.
3. If for any reason these operations do not restore the pump to full service, call your dealer or service technician.
4. Do not, in any case, open the sealed part of the pump or remove the screws. this will void your warranty.



REPLACEMENT PARTS LIST

ITEM NO.	DESCRIPTION
1	Screen
2	Screws 8-18 x 1"
3	Volute
4	Impeller Assembly
5	Screw 8-32 x 1-3/16"

GEARBOX MAINTENANCE

CS-350/FS-350 SAWS

NOTE: Before performing any maintenance on the gearbox, turn the disconnect switch to the "OFF" position and lock it out for safety.

1. The gearbox oil level should be checked weekly and the recommended oil added as needed to maintain the proper level.
2. Oil changes should be done as indicated in the section on gearbox lubrication (page 1.2).
3. Keep the gearbox casting clean to allow maximum heat dissipation.
4. Check the mounting bolts for tightness after the first three months of use and annually thereafter.

BARFEED MAINTENANCE

LUBRICATION: Pump oil into the two oilers on the carriage vise and on the vise shafts and screw. Make sure the vise screw is free of chips. Clean and oil the barfeed ways regularly.

LIMIT SWITCHES: The Carriage Forward and Carriage Retracted limit switches can be adjusted by loosening the socket head screws on either side of the switch and sliding the switch and base as needed. The switches should be adjusted so that the switch just 'makes' as the carriage makes contact with the stop at either end of its travel.

The Carriage Out-of-Stock switch can be adjusted by loosening the screw in the switch arm. The arm should be set so that more than 3/16" to 1/4" of vise movement causes the switch to open (Input #200 on the programmable controller goes off)

The Barfeed Cover switch is adjusted in the same manner as the Out-of-Stock limit switch. It should be set so that the Barfeed Cover must be fully closed for the saw to operate.

VACUUM MAINTENANCE

NOTE: Before doing any maintenance or service, be sure that the vacuum unit is disconnected from the power source to prevent accidental starting.

CAST ALUMINUM AND SHEET METAL FITTINGS:

The cast aluminum blower impeller, as well as all sheet metal fittings are maintenance free and should not require any maintenance during the life of the unit. In a very dirty environment the blower impeller should be cleaned with a wire brush to prevent a build-up that could unbalance the blower. After cleaning the impeller, inspect for possible cracks or excessive wear, which can cause an imbalance.

MOTOR MAINTENANCE:

1. REMOVING DUST AND DIRT: Blow off the motor with low pressure air to remove dust or dirt. Air pressure above 50 PSI should not be used as high pressure may damage insulation and blow dirt under loosened tape. The operator performing this maintenance should always wear eye protection. Dust can cause excessive insulation temperatures.
2. LUBRICATION: Under normal conditions ball bearing motors will operate for five years without re-lubrication. Under continuous operation at higher temperatures (above 104°F ambient), or in dusty atmospheres, re-lubricate after one year. To re-lubricate the motor bearings, dis-assemble the motor and housings. The bearings are located in the end shields of the motor. Re-pack each bearing and fill the cavity in the back of the bearings 1/3 full with 'Alvania Grease #2' (Shell Oil Co.)

TROUBLE SHOOTING CHART

SYMPTOM	POSSIBLE CAUSE(S)	CORRECTION
Unit will not operate	1. Improper electrical connection.	1. Turn the power off. Make sure the unit is wired per the electrical diagram.
	2. Loose blower wheel.	2. Disconnect the power. Turn the haed assembly over and spin the wheel by hand. Re-position and tighten the set screws as needed.
Low suction or flow rate	1. Incorrect Rotation	1. Turn the unit off and watch the motor cooling wheel rotation as it stops. Rewire the motor if necessary.

TROUBLE SHOOTING CHART (continued)

SYMPTOM	POSSIBLE CAUSE(S)	CORRECTION
Low suction or flow rate	2. Suction hose too long	2. Place the unit closer to the saw and shorten the hose.
	3. Filter Plugged	3. See below

FILTER CLEANING:

If the air flow to the collector is reduced to the point that the pickup is marginal, the filter should be cleaned. The frequency of cleaning will depend on the size and type of material being picked up. Small and/or very fine chips may need cleaning more often.

Air flow and pickup will be retarded if the collection barrel is allowed to become too full. The level of dust/chips in the barrel should not be allowed to come closer than 12" from the bottom of the wire basket holder. Empty the barrel regularly. Check to see if chips have built up on the outside of the wire basket holder; brush these off with a brush. Do not use air; this may drive chips into the filter element. DO NOT use a wire brush; this may damage the filter element.

If the air flow is still reduced after emptying the barrel and cleaning the wire basket, the filter element should be cleaned. Remove the wire basket from the underside of the lid, take out both pieces of the filter element, clean them, and re-assemble the unit.

Remove the wire basket by removing the four bolts holding it to the bottom of the lid. Remove the two pieces of filter from the wire basket holder. Place the filters in warm soapy water and gently swirl the filters so as to dislodge any chips. Be careful not to distort the filter shapes. Rinse the filters in clean water and air dry. Lightly oil them with a lightweight motor oil.

Re-assemble the filters and wire basket to the lid. Be sure there is a good seal between the lid and the wire basket.

If cleaning the filter does not restore the air flow, it may be necessary to replace the filter elements. Contact your dealer or the factory for the new elements (Part No. CS-9011).

SPARE PARTS LIST
CA-350/FA-350 SAWS

Drive Belt (2 Req'd): CS-3468

Standard Vise Wear Plate (4 Total): CS-2470

Indicator Lamp Bulbs: CS-5031

Power Fuses (1-3FU): Bussman Type KTK-R
(FA-350 saws) Gould Type ATMR
Littlefuse Type KLK_R

208V or 230V saws use 30A fuses; 460V saws use 12A

NOTE: Some early saws used Bussman type FNQ fuses.

Control Circuit Fuses (FA-350 saws):

4FU (Transformer): Bussman FNM 2 1/2
Gould TRM 2 1/2
Littlefuse FLM 2 1/2

5FU (Coolant Pump): Bussman FNM 1 1/4
(if equipped) Gould TRM 1 1/4
Littlefuse FLM 1 1/4

6FU (Worklight): Bussman AGC 3/10
(if equipped) Gould GGC 3/10
Littlefuse 3AG 3/10

8FU (Programmable controller): Bussman AGC 2
(FA-350A) Gould GGC 2
Littlefuse 3AG 2

9FU (Programmable Counter): Bussman AGC 3/10
(FA-350A) Gould GGC 3/10
Littlefuse 3AG 3/10

230V Motor Brake Fuses (If equipped): Bussman FWH-35
(Also work for 208V) Gould A25X35-4
Littlefuse KLB-35
(NOTE: 2 req'd)

460V Motor Brake Fuses (If equipped): Bussman FWH-15
Gould A50P15-1
Littlefuse KLB-15
(NOTE: 2 req'd)

Vise Screw Brush (2 Req'd): CS-2467

SPARE PARTS LIST
CS-350/FS-350 SAWS

Blade Brush: SP-47

Standard Vise Wear Plate (4 Total): CS-2470-S

Indicator Lamp Bulbs: CS-5031

Power Fuses (1-3FU): Bussman Type KTK-R
Gould Type ATMR
Littlefuse Type KLK-R

208V or 230V saws use 30A fuses; 460V saws use 12A

NOTE: Some early saws used Bussman type FNQ fuses.

Coolant Pump Fuse (CS-350 saws): Bussman FNM 1 1/4

Control Circuit Fuses (FS-350 saws):

4FU (Transformer): Bussman FNM 2 1/2
Gould TRM 2 1/2
Littlefuse FLM 2 1/2

5FU (Coolant Pump): Bussman FNM 1 1/4
Gould TRM 1 1/4
Littlefuse FLM 1 1/4

6FU (Worklight): Bussman AGC 3/10
(if equipped) Gould GGC 3/10
Littlefuse 3AG 3/10

8FU (Programmable controller): Bussman AGC 2
(FS-350A) Gould GGC 2
Littlefuse 3AG 2

9FU (Programmable Counter): Bussman AGC 3/10
(FS-350A) Gould GGC 3/10
Littlefuse 3AG 3/10

Gearbox Oil (5 qts/change): Mobilgear #634 or SHC 634

Vise Screw Brush (2 Req'd): CS-2467

SPARE PARTS LIST
CA-350/FA-350 SAWS
CS-350/FS-350 SAWS

CYLINDER SEAL KITS

CYLINDER P/N		SEAL KIT P/N
CS-2316	(Saw Vise Cylinder)	CS-2316-PRK
CS-4014	(Head Lift Cylinder)	
	Hydrolite Cylinders	CS-4014-PRK
	Parker Cylinders	CS-4014P-PRK
CS-4014-1	Numatics Cylinders	CS-4014-1-PRK
CS-4015	(Carriage Feed Cylinder- 3 1/4" bore: handwheel is on side of barfeed)	CS-4016-PRK
CS-4016	(Carriage Vise Cylinder- Hydrolite)	CS-4016-PRK
CS-4016-1	(Carriage Vise Cylinder- Parker)	CS-4016-1-PRK
CS-4016-2	(Carriage Vise Cylinder- Numatics)	CS-4016-2-PRK
CS-4034	(Carriage Feed Cylinder- Parker)	CS-4014P-PRK
	2 1/2" bore: handwheel is at end of barfeed	
CS-4034-1	(Carriage Feed Cylinder- Numatics)	CS-4014-1-PRK

NOTES

TROUBLESHOOTING GUIDE - GENERAL

1. MACHINE WILL NOT START

- a) Check the main and control fuses.
- b) Check your in-house wiring.
- c) Check that the incoming voltage matches the saw wiring.
- d) Check the motor brake fuses (if equipped).
- e) Overload relay tripped-fix cause and reset.

2. MOTOR WILL NOT START AND IS BLOWING FUSES

- a) Check for a short in the supply wiring.
- b) Check for a short in the motor windings or leads.
- c) Check for proper fuses or circuit breakers.

3. WORKLIGHT WILL NOT LIGHT (if equipped)

- a) Check the fuse inside the electrical enclosure (6FU).
- b) Check the bulb.

4. BLADE STRIPS TEETH

- a) Too many teeth, causing each tooth to overload.
- b) Blade too coarse.
- c) Head feed pressure too high.
- d) Blade speed too slow.
- e) Rectangular pieces should be cut on the shortest side.
- f) Vise clamping pressure too low.
- g) Head feed speed too high.
- h) Wrong blade for the job.

5. CROOKED CUTS

- a) Feed pressure too high.
- b) Wrong blade for the application.
- c) The blade grind may be worn on one side.
- d) Head feed speed too fast.
- e) Workpiece not squarely clamped in vise.
- f) The adjusting collar may be loose in the head support, allowing the head to shift on the pivot bar.

6. COOLANT WILL NOT FLOW

- a) Check the coolant level in the tank.
- b) Check the pump for blockage-clean if necessary
(Refer to the maintenance sheets on the coolant pumps or spray mist units for details).
- c) Check for line blockage.
- d) Check the coolant pump fuse (5FU-flood coolant units)
- e) Make sure the flow valves are open (spray mist units)
- f) Make sure the coolant switch is on (if equipped)

TROUBLESHOOTING: M & PV SAWS

7. BLADE WILL NOT START

- a) Overload relay tripped - fix cause and reset.
- b) Safety switch in the handle not making contact (F-series saws only).

8. VISE WILL NOT CLAMP (PV saws)

- a) Air valve not releasing as the head is lowered.
- b) Make sure the air supply is on and the pressure regulator is set properly.

TROUBLESHOOTING: SEMI-AUTOMATIC SAWS

9. CYCLE LIGHT WILL NOT LIGHT

- a) Check the light bulb.
- b) Make sure the Head Up limit switch is tripped.
- c) Blade brake is still energized (if equipped)

10. CYCLE WILL NOT START

- a) Blade brake is still energized (if equipped)
- b) Timer 2TR is still energized to stop the last cycle.
- c) The Head Down limit switch is still tripped.

11. HEAD WILL NOT FEED

- a) The Head Down limit switch is still tripped.
- b) The Feed Speed valve is closed.
- c) The Feed Pressure is too low for the application.
- d) Make sure the air supply is on.
- e) The Head Raise solenoid is still energized.

12. HEAD WILL NOT RAISE

- a) The Head Down limit switch is not tripped.
- b) The Head Feed solenoid is still energized.
- c) The Head Up limit switch is still tripped.
- d) Make sure the air supply is on.
- e) Air pressure too low.

13. VISE WILL NOT CLAMP

- a) Solenoid valve is not energizing.
- b) Make sure the air supply is on.
- c) Air pressure too low.
- d) Check lines and fittings for leaks.
- e) Check seals for tears.

TROUBLESHOOTING: SEMI-AUTOMATIC SAWS
(continued)

14. VISE WILL NOT RELEASE

- a) Solenoid valve is not releasing.
- b) Timer 2TR is not energizing to stop the cycle.
- c) The Head Up limit switch is not tripped.

TROUBLESHOOTING: AUTOMATIC SAWS

15. CYCLE WILL NOT START

- a) Make sure the 'Operation' switch is in the 'Auto' position.
- b) The cycle will not start if the blade brake is on
- c) Make sure the Head Up limit switch is tripped.
- d) Make sure there is stock in the barfeed and that the carriage vise is set to within 3/32 to 1/8" of the stock to keep the Out of Stock limit switch tripped.
- e) The barfeed cover must be closed.
- f) The batch counter cannot read '0'

16. HEAD WILL NOT FEED

- a) The Head Down limit switch is still tripped.
- b) The Feed Speed valve is closed.
- c) The Feed Pressure is too low for the application.
- d) Make sure the air supply is on.
- e) The Head Raise solenoid is still energized.
- f) The blade brake is still energized (if equipped).
- g) The Carriage Forward limit switch is not tripped.
- h) The Batch Counter has reached its preset value.
- i) The Stroke Counter has not reached its preset.

17. HEAD WILL NOT RAISE

- a) The Head Down limit switch is not tripped.
- b) The Head Up limit switch is not releasing.
- c) The Head Feed solenoid is still energized.
- d) Make sure the air supply is on.
- e) The air pressure is too low.

18. SAW VISE WILL NOT CLAMP

- a) The Carriage Forward limit switch is not tripped
- b) The blade brake is still energized (if equipped).
- c) The Saw Vise Clamp solenoid is not energized.
- d) Make sure the air supply is on.
- e) The clamping pressure is too low.
- f) Check lines and fittings for leaks.
- g) Check seals for tears.

TROUBLESHOOTING: AUTOMATIC SAWS
(continued)

19. SAW VISE WILL NOT OPEN

- a) The Saw Vise Clamp solenoid is still energized.
- b) The Head Up limit switch is not tripped.
- c) The Carriage Retracted limit switch was not tripped before feeding the stock.
- d) The saw did not finish making the cut (The Head Down limit switch was not tripped).
- e) The saw vise was manually clamped tight (No room for the cylinder to extend or retract).

20. CARRIAGE WILL NOT RETRACT

- a) The Carriage Forward limit switch is not tripped
- b) The blade brake is still energized
- c) The Carriage Vise Clamp solenoid is energized.
- d) Make sure the air supply is on.
- e) The air pressure is too low.
- f) The saw head is not feeding at the start of a cycle.
- g) The Carriage Retracted limit switch is tripped.
- h) The Stroke Counter has reached its preset value.
- i) The Carriage Feed solenoid is still energized.
- j) The Carriage Retract solenoid is not energized.

21. CARRIAGE WILL NOT FEED

- a) The Carriage Forward limit switch is tripped
- b) The Saw Vise Clamp solenoid is energized.
- c) Make sure the air supply is on.
- d) The air pressure is too low.
- e) The Carriage Retract solenoid is energized.
- f) The Head Up limit switch is not tripped.


22. CARRIAGE VISE WILL NOT CLAMP

- a) The Head Up limit switch is not tripped.
- b) The Carriage Retract solenoid is energized.
- c) The saw did not finish making the cut (The Head Down limit switch was not tripped).
- d) The Carriage Retracted limit switch is not tripped
- e) Make sure the air supply is on.
- f) The air pressure is too low.

23. CARRIAGE VISE WILL NOT OPEN

- a) The Carriage Vise Clamp solenoid is not releasing
- b) The Saw Vise Clamp solenoid is not energized.
- c) The Carriage Retract solenoid is still energized.
- d) The Carriage Vise is manually clamped tight (No room for the cylinder to extend or retract).

TOOL KIT CIRCULAR SAWS



1	CS-1503	1 1/2 x 1 5/8 OPEN END WRENCH
2	CS-1504	5/8 x 3/4 OPEN END WRENCH
3	CS-1505	1/2" HEX KEY
4	CS-1506	3/8" HEX KEY W/SPRING
5	CS-1507	3/8" HEX KEY TEE WRENCH
6	CS-1508	1/4" HEX KEY
7	CS-1509	3/16" HEX KEY
8	CS-1510	5/32" HEX KEY
9	CS-1511	5/16" HEX KEY

CS-1500 FS SERIES AUTO/SEMI-AUTO

CS-1504
CS-1505
CS-1511
CS-1507
CS-1508
CS-1509
CS-1510

CS-1500-1 FA SERIES AUTO/SEMI-AUTO

CS-1503
CS-1504
CS-1505
CS-1506
CS-1508
CS-1509
CS-1510
CS-1511


CS-1500-2 FS/CS SERIES PV/MANUAL

CS-1507

CS-1500-3 FA/CA SERIES PV/MANUAL

CS-1503
CS-1506

WISE CYLINDER ASSEMBLY **CIRCULAR SAWS**




1	CS-2310	WISE CYLINDER BODY
2	CS-2311	WISE CYLINDER CAP
3	CS-2312	WISE CYLINDER PISTON (INCLUDES ROD)
4	CS-2313	O-RING: PARKER #2-160 N674-70
5	CS-2314	O-RING: PARKER #2-325 N674-70
6	CS-2315	O-RING: PARKER #2-426 N674-70
7	CS-2315A	ROD WIPER: PARKER #8600-0150-4181
8		
9		1/4-20 x 1 SHCS (6)

CS-2316-PRK COMPLETE SEAL KIT: INCLUDES ITEMS 4, 5, 6, AND 7

CS-2316 COMPLETE CYLINDER ASSEMBLY


NOTE: CYLINDERS BUILT BEFORE MAY, 1991 HAVE 1/8-27 NPT PORTS

LENGTH COUNTER PARTS CIRCULAR SAWS




- | | | |
|---|---------|---|
| 1 | CS-6805 | LENGTH COUNTER BRACKET |
| 2 | CS-6810 | BACKSTOP SCREW |
| 3 | CS-6811 | SNAP RING: TRUARC #5160-75 |
| 4 | CS-6812 | SNAP RING: TRUARC #5160-98 |
| 5 | CS-6815 | COUNTER: SIKO #0502-000-20-CCW-.750 |
| 6 | | 1/4-20UNCx3/4 SELF TAPPING HEX HEAD SCREW (2) |
| 7 | CS-6440 | BACKSTOP HANDWHEEL |

BACKSTOP ASSEMBLY CIRCULAR SAWS



1	CS-3530	SWITCH MOUNTING PLATE
2	CS-6432	INSERT
3	CS-6400-1	BACKSTOP
4	V20-6105	LIMIT SWITCH: OMRON #D4C-1631
5		
6		
7		#10-24x7/8 SOCKET HEAD CAP SCREW (2)
8		#10-24x1 ROUND HEAD MACHINE SCREW (BRASS) (2)
9		1/4-20 x 3/4 SOCKET HEAD CAP SCREW (2)
10		5/8-11x2 1/2 SOCKET HEAD CAP SCREW
11		
12		#10-24 BRASS HEX NUT (2)
13		
14		1/4 FLAT WASHER (MODIFIED) (2)


BARFEED CARRIAGE CIRCULAR SAWS



- | | | |
|---|-----------|------------------------------------|
| 1 | CS-6252 | WISE WEAR PLATE (2) (FA-350A ONLY) |
| | CS-6252-S | WISE WEAR PLATE (2) (FS-350A ONLY) |
| 2 | CS-4016 | CARRIAGE VISE CYLINDER |
| 3 | CS-5046 | LIMIT SWITCH |
| 4 | CS-6100-1 | BARFEED CARRIAGE |
| 5 | CS-6200-1 | CARRIAGE VISE REAR JAW |
| 6 | CS-6210 | MOVING VISE BLOCK |
| 7 | CS-6215 | VISE BLOCK GUIDE PIN (2) |
| 8 | CS-6220 | VISE CYLINDER EXTENSION |


- | | | |
|----|-----------|-------------------------|
| 9 | CS-6230 | OUT OF STOCK TRIGGER |
| 10 | CS-6250-1 | CARRIAGE VISE FRONT JAW |
| 11 | CS-6255 | CARRIAGE VISE SCREW |
| 12 | CS-6260 | BARFEED HANDWHEEL |
| 13 | CS-6270-1 | VISE SHAFT (2) |
| 14 | V21-3234 | BRONZE BEARING (4) |
| 15 | | 3/16 x 1 1/4 ROLL PIN |

BARFEED CARRIAGE OVERHEAD ROLLER CIRCULAR SAWS



1	CS-6335	BARFEED ROLLER
2	CS-6340	BRONZE BEARING: BOSTON #P50-6 (2)
3	CS-6550	OVERHEAD ROLLER SUPPORT PLATE
4	CS-6555	OVERHEAD ROLLER GUIDE (2)
5	CS-6556	OVERHEAD ROLLER TOP PLATE
6	CS-6558	OVERHEAD ROLLER SUPPORT BLOCK (2)
7		1/8 x 1 1/4 ROLL PIN (2)
8		1/4-20 x 1/2 SHCS (4)
9		5/16-18 x 2 1/4 SHCS (2)
10		3/8-16 x 1 1/4 SHCS (2)


STOCK STOP ASSEMBLY CIRCULAR SAWS



CS-7000 COMPLETE ASSEMBLY


1	CS-7010	STOP BLOCK
2	CS-7015	STOP ROD ASSY.
3	CS-7030	STOP SUPPORT
4	CS-7040	STOP SHAFT
5	AB-18115	ADJUSTING KNOB

"P" SERIES STOCK STANDS




1	P-1001	STOCK STAND BASE
2	P-2	STOCK STAND YOKE
3	P-103	STOCK STAND NUT
4	P-104	STOCK STAND SCREW: 21'-30' STANDS
	P-114	STOCK STAND SCREW: 30'-39' STANDS
	P-124	STOCK STAND SCREW: 37'-46' STANDS
5	P-5	STOCK STAND ROLLER
6		1/2 x 3 STEEL CLEVIS PIN
7		1/8 x 1 COTTER PIN

ROLLER TABLES




RT-0507





RT-1007

ROLLER TABLE STOCK STOP RTS-07



- | | | |
|---|---------|---------------------|
| 1 | 8C-1915 | TIGHTENER KNOB |
| 2 | RTS-071 | STOCK STOP WELDMENT |



FIXTURE MOUNTING TABLE CIRCULAR SAWS



SLOTS FOR 3/8 "T" NUTS (4)

- | | | |
|---|---------|-------------------------|
| 1 | CS-7610 | WORKTABLE WELDMENT |
| 2 | CS-7615 | WORKTABLE CENTER PLATE |
| 3 | | 5/8-11 x 5 1/2 SHCS (2) |

OVERHEAD CLAMP CIRCULAR SAWS




3.13

CS-7500 COMPLETE ASSEMBLY

- | | | |
|---|-----------|-----------------------------|
| 1 | CS-7505 | CYLINDER MOUNT |
| 2 | CS-7510 | CLAMP BAR |
| 3 | CS-7515-1 | CYLINDER: HUMPHREY #5-D-1/2 |
| 4 | CS-7520 | GUIDE RODS (2) |
| 5 | CS-7525 | ADJUSTING NUT (4) |



NOTE: SAWS BEFORE S/N 241 USE THE CS-7515
CYLINDER INSTEAD OF A CS-7515 CYLINDER

SHORT LENGTH
STOCK STOP
OPTION




- | | | |
|---|-----------|---|
| 1 | CS-7401 | 90 DEG. WEAR PLATE (FA/CA SAWS ONLY) (3) |
| | CS-7401-S | 90 DEG. WEAR PLATE (FS/CS SAWS ONLY) (3) |
| 2 | CS-7402 | STOCK STOP WEAR PLATE (FA/CA SAWS ONLY) |
| | CS-7402-S | STOCK STOP WEAR PLATE (FS/CS SAWS ONLY) |
| 3 | CS-7403 | STOCK STOP WELDMENT |
| 4 | V20-7117A | PRESSURE GAUGE: PARKER #P77413 (FA/CA SAWS ONLY) |
| 5 | V20-7117B | PRESSURE REGULATOR: PARKER #14R113F (FA/CA SAWS ONLY) |
| 6 | | MOUNTING BRACKET: PARKER #PS417B (FA/CA SAWS ONLY) |
| 7 | V20-7118 | MOUNTING NUT: PARKER #P78652 (FA/CA SAWS ONLY) |
| 8 | V20-9032B | *T* NUT: REID #TN-2 |

STOCK STOP SLIDES IN T-SLOT TO ANY LENGTH DESIRED




BASE COMPONENTS CA-350/CA-350PV



1	CS-1000	BASE CABINET
2	CS-1205	DOOR LATCH SPRING
3	CS-1208	DOOR GROMMET
4	8C-212	'KALAMAZOO' LOGO
5	9A-5040	MOTOR SWITCH ASSEMBLY (SEE PAGE 8.25)
6	V20-7300	SPRAY MIST UNIT- 1 QT. RESERVOIR
7	CS-2227	PLASTIC GRIP (CA-350/CA-350PV)
8	CS-2225	ARM
9	CS-2100	SAW BED
10	CS-2200	HEAD ROTATION CASTING
11		HEAD ASSEMBLY (SEE FIG. 4.6)
12	CS-3200	HEAD FRAME SUPPORT
13	CS-3582	HEAD RETURN SPRING
14	CS-3800	RETRACTOR BRACKET ASSEMBLY
15	CS-3810	RETRACTOR SHAFT ASSEMBLY
16	CS-3900	BLADE GUARD ASSEMBLY
17		
18	CS-3910	BELT GUARD ASSEMBLY
19	V20-2202	3 HP MOTOR, 1750 RPM, 184 FRAME
20	CS-4013	FILTER/REGULATOR/LUBRICATOR (PV MODELS)
21		WISE ASSEMBLY (SEE FIG. 4.5)
22	CS-2500	SPLASH GUARD - MANUAL VISE (2)
	CS-2510	SPLASH GUARD - POWERED VISE (2)
23	CS-5054-1	LIMIT SWITCH TRIGGER (CA-350PV)
24	CS-4020-1	VISE CLAMP AIR VALVE (CA-350PV)


REVISED 6/5/92

BASE COMPONENTS FA-350/FA-350PV




1	CS-1000	BASE CABINET
2	CS-1205	DOOR LATCH SPRING
3	CS-1208	DOOR GROMMET (3)
4	CS-2710	ANGLE STOP BLOCK (3)
5	CS-2100	SAW BED
6	CS-2200	HEAD ROTATION CASTING
7		HEAD ASSEMBLY (SEE FIG. 4.6)
8	CS-3200	HEAD FRAME SUPPORT
9	CS-3582	HEAD RETURN SPRING
10	CS-3600	HANDLE SWITCH ASSEMBLY
11	CS-3800	RETRACTOR BRACKET ASSEMBLY
12	CS-3810	RETRACTOR SHAFT ASSEMBLY
13	CS-3900	BLADE GUARD ASSEMBLY
14		
15	CS-3910	BELT GUARD ASSEMBLY
16	CS-5000	SWITCH PANEL ASSEMBLY (SEE FIG. 8.3)
17	CS-7000	STOCK STOP ASSEMBLY (SEE FIG. 3.8)
18	8C-212	'KALAMAZOO' LOGO
19	V20-2202	3HP MOTOR, 1750 RPM, 184 FRAME
20	CS-4013	FILTER/REGULATOR/LUBRICATOR ASS'Y
21	V20-7300	SPRAY MIST UNIT (1 QT RESERVOIR)
22	CS-PV	WISE ASSEMBLY (SEE FIG. 4.5)
23	CS-2510	SPLASH GUARD - POWERED WISE (2)
24	CS-5054-1	LIMIT SWITCH TRIGGER
25	CS-4020-1	AIR VALVE

BASE COMPONENTS FA-350SA





1	CS-1000	BASE CABINET
2	CS-1205	DOOR LATCH SPRING
3	CS-1208	DOOR GROMMET (3)
4	CS-2710	ANGLE STOP BLOCK (3)
5	CS-2100	SAW BED
6	CS-2200	HEAD ROTATION CASTING
7		HEAD ASSEMBLY (SEE FIG. 4.6)
8	CS-3200	HEAD FRAME SUPPORT
9		HEAD LIFT ASSEMBLY (SEE FIG. 4.9)
10	CS-5080	CONTROL CONSOLE ASS'Y (SEE FIG. 8.5)
11	CS-3800	RETRACTOR BRACKET ASSEMBLY
12	CS-3810	RETRACTOR SHAFT ASSEMBLY
13	CS-3900	BLADE GUARD ASSEMBLY
14		
15	CS-3910	BELT GUARD ASSEMBLY
16	CS-7000	STOCK STOP ASSEMBLY (OPTION-SEE FIG. 3.8)
17	8C-212	"KALAMAZOO" LOGO
18	V20-2202	3HP MOTOR, 1750 RPM, 184 FRAME
19	CS-4013	FILTER/REGULATOR/LUBRICATOR ASSEMBLY
20	CS-4003-1	AIR/OIR RESERVOIR ASS'Y (SEE FIG. 7.1)
21	CS-5081	CONTROL CONSOLE BRACKET
22	CS-9062	SPRAY MIST UNIT-1 GAL RESERVOIR
23	CS-PV	WISE ASSEMBLY (SEE FIG. 4.5)
24	CS-2510	SPLASH GUARD - POWERED VISE (2)
25	CS-4017-1	FEED SPEED VALVE
26	CS-4042	FEED SPEED OVERLAY

BASE COMPONENTS **FA-350A**



1	CS-6700	BASE CABINET
2	CS-1205	DOOR LATCH SPRING (2)
3	CS-1208	DOOR GROMMET (4)
4	CS-2100	SAW BED
5	CS-2200	HEAD ROTATION CASTING
6		HEAD ASSEMBLY (SEE FIG. 4.6)
7	CS-3200	HEAD FRAME SUPPORT
8		POWERED HEAD LIFT PARTS (SEE FIG. 4.9)
9	CS-5002-1	CONTROL CONSOLE ASS'Y (SEE FIG. 8.6)
10	CS-3800	RETRACTOR BRACKET ASSEMBLY
11	CS-3810	RETRACTOR SHAFT ASSEMBLY
12	CS-3900	BLADE GUARD ASSEMBLY
13	CS-4042	FEED SPEED OVERLAY
14	CS-3910	BELT GUARD ASSY.
15	CS-7045	DISCHARGE SLIDE
16	H-15301	'KALAMAZOO' LOGO
17	V20-2202	3HP MOTOR, 1750 RPM, 184 FRAME
18	CS-4013	FILTER/REGULATOR/LUBRICATOR ASSEMBLY
19	CS-4003-1	HEAD LIFT AIR/OIR RESERVOIR ASS'Y (SEE FIG. 7.1)
20	CS-6770	BARFEED CARRIAGE COVER
21	CS-9062	SPRAY MIST UNIT-1 GAL RESERVOIR
22	\$CS-PV	VICE ASSEMBLY (SEE FIG. 4.5)
23	CS-2510	SPLASH GUARD - POWERED VISE (2)
24	CS-4017-1	FEED SPEED VALVE
25	CS-6000	BARFEED ASSY. (SEE FIG. 3.3)
26	CS-2710	ANGLE STOP BLOCK (2)
27	CS-5046	LIMIT SWITCH
28	CS-4060	CARRIAGE FEED AIR/OIR RESERVOIR ASS'Y (SEE FIG. 7.2).

NOTE: HANDWHEEL, ETC. OMITTED
FOR CLARITY IN THIS VIEW



1	CS-2200	HEAD ROTATION CASTING
2	CS-2210	VISE PIVOT SHAFT
3	CS-2211	PIVOT SHAFT KEY
4	CS-2215	SHAFT LOCK BASE
5	CS-2220	SHAFT LOCK PLATE
6	CS-2225	SHAFT LOCK ARM
7	CS-2227	PLASTIC GRIP
8	CS-2710	ANGLE STOP BLOCK (3)
9	CS-2205	ANGLE SCALE
10	CS-8301	SCREW COVER (2)
11	CS-2300	VISE SUPPORT CASTING
12	CS-2316	VISE CYLINDER ASSY (MACHINES W/ POWER VISE)
13	CS-2320	FRONT VISE JAW
14	CS-2325	REAR VISE JAW
15	CS-2328	VISE SHAFT (2)
16	CS-2330	FRONT VISE JAW ADAPTER (MACHINES W/ MANUAL VISE)


17	CS-2450	VISE SCREW RETAINER
18	CS-2460	VISE SCREW ASSEMBLY
19	CS-2468	VISE SCREW COLLAR
20	CS-2470	WEAR PLATE (4) - ALUMINUM
21	9A-11502	VISE HANDWHEEL
22	9A-11504	HANDWHEEL NUT
23	H-40331B	FLUSH OILER (2)
24	CS-8302	BUSHING
25	CS-8303	BUSHING
26		5/8-11 x 4 1/2 SHCS (2)
27		1/2 FLATWASHER
28		5/8-11 x 2 SHCS (4)
29		5/8-11 SQUARE NUT (4)
30		1/4-20 x 3 1/2 SHCS (2)
31	S-113	KEY
32	CS-2467	VISE SCREW BRUSH (2)
33	CS-2322	DRAG SCREW (5)
34		1/4-20 x 1 1/4 SHSS

NEW & VISE ASSEMBLY
CA-350/FA-350 SAWS

REVISED 6/5/92


4.5

HEAD COMPONENTS FA-350 SAWS



1	CS-3100	HEAD FRAME ASSEMBLY
2	CS-3300	MOTOR MOUNTING PLATE
3	CS-3465	DRIVE PULLEY
4	CS-3468	DRIVE BELT: DAYCO #3VX500 (2)
5	CS-3600	BLADE SWITCH HANDLE ASSEMBLY (FA-350/FA-350PV ONLY)
	CS-2225	SHAFT LOCK ARM (CA-350/CA-350PV)
	CS-2227	PLASTIC GRIP (CA-350/CA-350PV)
6	CS-3830	LOWER BLADE GUARD
7	CS-3900	BLADE GUARD ASSEMBLY
8	CS-3849	DEFLECTOR FLAP
9	CS-3910	BELT GUARD
10	CS-3920	BELT GUARD SUPPORT
11	CS-3930	BELT GUARD BACK PLATE
12	V20-2202	3 HP MOTOR: BALDOR #M3611
13		SPINDLE ASSEMBLY - SEE FIG 4.7
14	CS-3857	AIR BAFFLE
15	CS-3857A	AIR BAFFLE BLADE (PLASTIC)


SPINDLE ASSY FA-350 SAWS



NOTE PROPER ORIENTATION OF
OFF-CENTER LOCATING HOLE:
'LONG' SIDE SHOULD BE TOWARD
THE 'BLADE' SIDE OF THE SPINDLE
(INSTEAD OF THE 'PULLEY' SIDE)


	CS-3401	BLADE SPINDLE SUB-ASSEMBLY (INCLUDES ITEMS 1, 4, 5, AND 6)
1	CS-3400	BLADE SPINDLE
2	CS-3410	SPINDLE WASHER
3	CS-3420	SPINDLE NUT (NOTE: LEFT HAND THREAD)
4	CS-3430	OUTER BEARING SPACER
5	CS-3440	INNER BEARING SPACER
6	CS-3445	BEARING: SKF #62052RS (2)
7	CS-3450	PULLEY SPACER
8	CS-3460	DRIVEN PULLEY
9	V20-2142	KEY: 1/4 SQUARE x 7/8 LONG
10		7/8-9 LOCK NUT
11	CS-3100	HEAD FRAME CASTING (REF)
12	CS-3910	BELT GUARD (REF)

MANUAL HEAD LIFT FA-350M




1	CS-3100	HEAD FRAME CASTING
2	CS-3150	CLEVIS BRACKET
3	CS-3200	HEAD SUPPORT CASTING
4	CS-3260	ADJUSTING RING COLLAR
5	CS-3265	ADJUSTING RING NUT
6	CS-3300	MOTOR MOUNTING PLATE
7	CS-3575	SNAP RING: TRUARC #X-5133-74
8	CS-3585	SPRING ROLLER
9	CS-3582	SPRING: ASSOCIATED #E1500-148-4500M
10	CS-3590	ROLLER BRACKET ASSEMBLY
11	CS-3596	SPRING SLEEVE
12	CS-3598	SPRING PIN
13	V20-2202	3 HP MOTOR
14	CS-3250	HEAD PIVOT SHAFT

POWERED HEAD LIFT FA-350




1	CS-3100	HEAD FRAME CASTING
2	CS-3150	CLEVIS BRACKET
3	CS-3200	HEAD SUPPORT CASTING
4	CS-3260	ADJUSTING RING COLLAR
5	CS-3265	ADJUSTING RING NUT
6	CS-3300	MOTOR MOUNTING PLATE
7	CS-3510	CYLINDER MOUNTING BRACKET
8	CS-3520	CYLINDER MOUNT
9	CS-3530	SWITCH MOUNTING PLATE (2)
10	CS-3550	STOP COLLAR (2)
11	CS-3560	STOP ROD CLEVIS ASSEMBLY
12	CS-3570	CLEVIS PIN
13	CS-3575	SNAP RING: TRUARC #X-5133-74
14	CS-3580	CYLINDER CLEVIS: PARKER #50942
15	CS-4014	CYLINDER: 2 1/2" BORE x 3 3/4" STROKE
16	CS-5057	LIMIT SWITCH: OMRON #D4C-1603
17	V20-2202	3 HP MOTOR: 1750 RPM, 184 FRAME
18		5/8 x 1 SOCKET HEAD SHOULDER SCREW
19	CS-3250	HEAD PIVOT SHAFT

BLADE GUARD PARTS FA-350




1	CS-3100	HEAD FRAME CASTING (REF)
2	CS-3200	HEAD SUPPORT CASTING (REF)
3	CS-3300	MOTOR MOUNTING PLATE (REF)
4	CS-3800	RETRACTOR BRACKET ASSY
5	CS-3810	RETRACTOR SHAFT
6	CS-3820	RETRACTOR ARM
7	CS-3825	1/4-20 ELASTIC STOP NUT
8	CS-3830	LOWER BLADE GUARD
9		
10	CS-3847	SNAP RING: TRUARC #5100-150
11	CS-3848	COOLANT ADAPTER
12	CS-3849	FLAP
13	CS-3900	BLADE GUARD ASSEMBLY
14	CS-3857	AIR BAFFLE (METAL)
15	CS-3857A	AIR BAFFLE BLADE (PLASTIC)
16	V20-2202	3 HP MOTOR: 1750 RPM, 184 FRAME (REF)
17	CS-8222	BLADE CAUTION DECAL
18	CS-3839	WARNING DECAL
19	CS-3849A	FLAP BRACKET

CHIP COLLECTOR PARTS CA-350/FA-350 SAWS




1	CS-9005	CHIP COLLECTOR: CINCINNATI #300S
2	CS-9006	REDUCER: 6" x 4"
3	CS-9007	BUSHING: 4" x 2"
4	CS-9008	HOSE NIPPLE: 2"NPT x 2" HOSE
5	CS-9009	VACUUM HOSE: 2" ID x 6' LONG
6	CS-9010	55 GAL BARREL
7	CS-9011	REPLACEMENT FILTER ELEMENT
8	9A-220B	MOTOR SWITCH: 230V/3PH
	9A-220C	MOTOR SWITCH: 460V
	9A-220E	MOTOR SWITCH: 208V

CHIP COLLECTOR GUARDS FA-350



1	CS-9002	CHIP COLLECTOR
2	CS-9003	RH SIDE COVER
3	CS-9004	LH SIDE COVER
4	CS-9008	HOSE NIPPLE: 2" NPT x 2" HOSE
5	CS-9009	VACUUM HOSE: 2" ID x 6' LONG
6	CS-9003A	RH SIDE COVER EXTENSION
7		1/4-20 x 1/2 SHCS (3-NOT SHOWN)


BASE COMPONENTS CS-350/CS-350PV



1	CS-1000	BASE CABINET
2	CS-1205	DOOR LATCH SPRING
3	CS-1208	DOOR GROMMET (3)
4	8C-212	'KALAMAZOO' LOGO
5	9A-5040	BLADE MOTOR SWITCH
6	CS-17058	COOLANT TANK SHELF
7	CS-1730	COOLANT TANK
8	CS-1735	SPLASH GUARD (AROUND COOLANT TANK)
9	CS-2100	SAW BED
10	CS-2200	HEAD ROTATION CASTING
11		HEAD ASSEMBLY (SEE FIGS. 5.11 AND 5.12)
12	CS-3210	HEAD FRAME SUPPORT
13	CS-8201	HEAD RETURN SPRING (2)
14	CS-3820	RETRACTOR ARM
15	CS-3822	RETRACTOR EXTENSION
16	CS-3905	BLADE GUARD ASSEMBLY
17		
18	CS-8400-A	BLADE BRUSH ASSEMBLY (SEE FIG. 5.8)
19	CS-8205A	3/1.5 HP MOTOR, 208/230V
	CS-8205B	3/1.5 HP MOTOR, 460V
20	CS-4013	FILTER/REGULATOR/LUBRICATOR (PV MODELS)
21		WISE ASSEMBLY (SEE FIG. 5.5)
22	CS-2500	SPLASH GUARD - MANUAL VISE (2)
	CS-2510	SPLASH GUARD - POWERED VISE (2)
23	CS-5054-1	LIMIT SWITCH TRIGGER
24	CS-4020-1	VISE CLAMP AIR VALVE
25	CS-5064-1	MOTOR SPEED SWITCH (COMPLETE)
	CS-5064-1A	SPEED SWITCH OVERLAY
	CS-5064-1B	SPEED SWITCH OPERATOR
	CS-5064-1C	SPEED SWITCH CONTACT BLOCK
26	CS-2227	PLASTIC GRIP
27	CS-2225	ARM


REVISED 6/5/92

BASE COMPONENTS FS-350SA



1	CS-1000	BASE CABINET
2	CS-1205	DOOR LATCH SPRING
3	CS-1208	DOOR GROMMET (3)
4	CS-1300S	COOLANT TANK ASSEMBLY (SEE FIG. 5.6)
5	CS-2710	ANGLE STOP BLOCK (3)
6	CS-2100	SAW BED
7	CS-2200	HEAD ROTATION CASTING
8		HEAD ASSEMBLY (SEE FIG. 5.11 AND 5.12)
9	CS-3210	HEAD FRAME SUPPORT
10	CS-8201	HEAD RETURN SPRING
11		HEAD LIFT ASSY. (SEE FIG. 5.10)
12	CS-3822	RETRACTOR EXTENSION
13	CS-3820	RETRACTOR ARM
14	CS-8159	BLADE GUARD ASSEMBLY
15		
16	CS-8400-A	BLADE BRUSH ASSEMBLY (SEE FIG. 5.8)
17	CS-4013	FILTER/REGULATOR/LUBRICATOR ASSY.
18	CS-5080	CONTROL CONSOLE ASSEMBLY (SEE FIG. 8.5)
19	CS-7000	STOCK STOP ASSEMBLY (OPTION:SEE FIG. 3.8)
20	C-16	CHIP PAN
21	8C-212	'KALAMAZOO' LOGO
22	CS-8205A	3/1.5 HP MOTOR, 1750/825 RPM, 208/230V
	CS-8205B	3/1.5 HP MOTOR, 1750/825 RPM, 460V
23	CS-2517	DRIP GUARD
24	CS-PVS	WISE ASSEMBLY (SEE FIG. 5.5)
25	CS-2510	SPLASH GUARD - POWER VISE (2)
26	CS-5081	CONTROL CONSOLE BRACKET
27	CS-4003-1	AIR/OIL RESERVIOR ASSY. (SEE FIG. 7.1)
28	CS-4017-1	FEED SPEED VALVE
29	CS-4042	FEED SPEED OVERLAY


BASE COMPONENTS FS-350A



1	CS-6700	BASE CABINET
2	CS-1205	DOOR LATCH SPRING (2)
3	CS-1208	DOOR GROMMET (4)
4	CS-2100	SAW BED
5	CS-2200	HEAD ROTATION CASTING
6		HEAD ASSEMBLY (SEE FIG. 5.11 AND 5.12)
7	CS-3210	HEAD FRAME SUPPORT
8		HEAD LIFT ASSEMBLY (SEE FIG. 5.10)
9	CS-5002-1	CONTROL CONSOLE ASS'Y (SEE FIG. 8.6)
10	CS-3820	RETRACTOR ARM
11	CS-3822	RETRACTOR EXTENSION
12	CS-3905	BLADE GUARD ASSEMBLY
13		
14	C-16	CHIP PAN
15	CS-7045	DISCHARGE SLIDE
16	H-15301	'KALAMAZOO' LOGO
17	CS-8205A	3/1.5 HP MOTOR, 1750/825 RPM, 208/230V
	CS-8205B	3/1.5 HP MOTOR, 1750/825 RPM, 460V
18	CS-4013-1	FILTER/REGULATOR/LUBRICATOR ASSEMBLY
19		HEAD AIR/OIR RESERVOIR ASS'Y (SEE FIG. 7.1)
20	CS-6770	BARFEED CARRIAGE COVER
21	CS-2517	DRIP GUARD
22	CS-PVS	WISE ASSEMBLY (SEE FIG. 5.5)
23	CS-2510	SPLASH GUARD - POWERED WISE (2)
24	CS-4017-1	FEED SPEED VALVE
25	CS-6000	BARFEED ASSY. (SEE FIG. 3.3)
26	CS-2710	ANGLE STOP BLOCK (2)
27	CS-1300S	COOLANT TANK ASSY. (SEE FIG. 5.6)
28	CS-8400A	BLADE BRUSH ASSY. (SEE FIG. 5.8)
29	CS-4060	CARRIAGE AIR/OIR RESERVOIR ASS'Y (SEE FIG. 7.2)

BED & VISE ASSEMBLY **CS-350/FS-350 SAWS**

NOTE: HANDWHEEL, ETC. OMITTED
FOR CLARITY IN THIS VIEW




5 PLACES-2 AS SHOWN,
2 IN REAR JAW, AND 1
IN REAR JAW UNDER
VISE SCREW

1	CS-2200	HEAD ROTATION CASTING
2	CS-2210	VISE PIVOT SHAFT
3	CS-2211	PIVOT SHAFT KEY
4	CS-2215	SHAFT LOCK BASE
5	CS-2220	SHAFT LOCK PLATE
6	CS-2225	SHAFT LOCK ARM
7	CS-2227	PLASTIC GRIP
8	CS-2710	ANGLE STOP BLOCK (3)
9	CS-2205	ANGLE SCALE
10	CS-8301	SCREW COVER (2)
11	CS-2300	VISE SUPPORT CASTING
12	CS-2316	VISE CYLINDER ASSY (MACHINES W/ POWER VISE)
13	CS-2320	FRONT VISE JAW
14	CS-2325	REAR VISE JAW
15	CS-2328	VISE SHAFT (2)
16	CS-2330	FRONT VISE JAW ADAPTER (MACHINES W/ MANUAL VISE)

17	CS-2450S	VISE SCREW RETAINER
18	CS-2460	VISE SCREW ASSEMBLY
19	CS-2468	VISE SCREW COLLAR
20	CS-2470S	WEAR PLATE (4)
21	9A-11502	VISE HANDWHEEL (POWER VISE)
	CS-8500	VISE HANDLE (MANUAL VISE)
22	9A-11504	HANDWHEEL NUT
23	H-40331B	FLUSH OILER (2)
24	CS-8302	BUSHING
25	CS-8303	BUSHING
26		5/8-11 x 4 1/2 SHCS (2)
27		1/2 FLATWASHER
28		5/8-11 x 2 SHCS (4)
29		5/8-11 SQUARE NUT (4)
30		1/4-20 x 3 1/2 SHCS (2)
31	S-113	KEY
32	CS-2467	VISE SCREW BRUSH (2)
33	CS-2322	DRAG SCREW (5)
34		1/4-20 x 1 1/4 SHSS


COOLANT TANK ASSEMBLY CIRCULAR SAWS



1	C-16	CHIP PAN
2	C-49	1/4 NPTF TO 3/8 HOSE FITTING
3	C-855	3/8 ID HOSE x 6' LONG
4	CS-1300	COOLANT TANK
5	CS-1308	COOLANT TANK SUPPORT
6	H3-3005	9/16 WIRE HOSE CLAMP (2)
7	JIC-431	COOLANT PUMP: LITTLE GIANT #1-YS (W/OUT SWITCH)
8		1/2 NPT PLUG
9		1/2 NPT PIPE COUPLING
10		1/2 NPT x 1 1/2 NIPPLE
11		1/2" CONDUIT NUT (2)


NOTE: UNITS WITH A FLUSHING HOSE USE
PUMP P/N H-106 IN PLACE OF P/N JIC-431

BLADE GUARD PARTS CS-350/FS-350




1	CS-3822	RETRACTOR EXTENSION
2	CS-3820	RETRACTOR ARM
3	CS-3825	1/4-20 ELASTIC STOP NUT
4	CS-8620	LOWER BLADE GUARD
5	CS-3847	SNAP RING: TRUARC #5100-0150
6		
7	CS-3905	BLADE GUARD ASSEMBLY
8	CS-8222	BLADE CAUTION DECAL
9	CS-8400-A	BLADE BRUSH ASSEMBLY (SEE FIG. 5.8)
10	C-12	COOLANT VALVE
11		3/8-16 THUMB SCREW (2)

BLADE BRUSH ASSEMBLY **CS-350/FS-350 SAWS**




- | | | |
|---|---------|--|
| 1 | CS-8400 | BLADE BRUSH BRACKET |
| 2 | SP-47 | BLADE CLEANING BRUSH |
| 3 | 9A-273 | 1/2 DIA x 5/8 LG.
SOCKET HEAD SHOULDER SCREW |
| 4 | 9A-272 | BLADE BRUSH SPACER |
| 5 | | 3/8 FLAT WASHER |
| 6 | | 3/8 LOCK WASHER |
| 7 | | 3/8-16UNC x 3/4 WINGHEAD
SHOULDER THUMB SCREW |
| 8 | | 3/8-16 UNC HEX NUT |

HEAD FRAME PARTS **CS-350 / CS-350PV** **FS-350 / FS-350PV**




1	CS-3210	HEAD SUPPORT CASTING
2	CS-8610	PIVOT SHAFT
3	CS-3260	ADJUSTING RING COLLAR
4	CS-3265	ADJUSTING RING NUT
5	CS-3598	SPRING PIN
6	CS-3575	SNAP RING: TRUARC #X-5133-74 (2)
7	CS-3596	SPRING SLEEVE (2)
8	CS-4020-1	AIR VALVE (CS-350PV/FS-350PV ONLY)
9	CS-5054-1	LIMIT SWITCH TRIGGER (CS-350PV/FS-350PV ONLY)
10	CS-3150	CLEVIS BRACKET
11	CS-8201	HEAD RETURN SPRING
12	CS-8202-1	SPRING BRACKET
13		3/4 SAE FLAT WASHER (7)

POWERED HEAD PARTS FS-350SA/FS-350A



1	CS-3210	HEAD SUPPORT CASTING
2	CS-8610	PIVOT SHAFT
3	CS-3260	ADJUSTING RING COLLAR
4	CS-3265	ADJUSTING RING NUT
5	CS-3510	CYLINDER MOUNT BRACKET
6	CS-3520	CYLINDER MOUNT
7	CS-3530	SWITCH MOUNTING PLATE (2)
8	CS-3550	STOP COLLAR (2)
9	CS-3560	STOP ROD CLEVIS ASSEMBLY
10	CS-3570	CLEVIS PIN
11	CS-3575	SNAP RING: TRUARC #X-5133-74
12	CS-3580	CYLINDER CLEVIS: PARKER #50942
13	CS-8230	SPRING ROLLER (2)
14	CS-4014	CYLINDER: 2 1/2" BORE x 3 3/4" STROKE
15	CS-5057	LIMIT SWITCH: OMRON #D4C-1603 (2)
16	CS-8100-1	GEARBOX CASTING
17	CS-3150	CLEVIS BRACKET
18	CS-8201	HEAD RETURN SPRING
19	CS-8205A	MOTOR: 1.5/3 HP (208/230V)
	CS-8205B	MOTOR: 1.5/3 HP (460V)
20	CS-8203	ASSIST SPRING BRACKET
21	X-143	5/8 x 1 SOCKET HEAD SHOULDER SCREW
22		5/8 x 1 1/2 SOCKET HEAD SHOULDER SCREW
23		5/8 SAE FLAT WASHER (2)


GEARBOX ASSEMBLY 1 FS-350 SAWS



1	CS-8100	GEARBOX CASTING
2	CS-8154	WORM GEAR
3	CS-8156	LARGE BEARING ASSEMBLY
4	CS-8158	BEARING RETAINER
5	CS-8160	SPINDLE SHAFT
6	CS-8165	SPINDLE DRIVE PLATE
7	CS-8220	OIL FILLER PLUG
8	CS-8221	SIGHT LEVEL GAUGE
9	X-116	BACK COVER


10	X-124	BACK COVER SHIM
11	X-133	SMALL BEARING ASSEMBLY
12		1/4-20 x 7/8 SHCS (4)
13		3/8-16 x 7/8 HHCS (4)
14		1/2-13 x 1 1/2 SHCS
15		#TX WOODRUFF KEY (3/8 x 2 NOMINAL)
16	CS-8171	RETAINING RING
17	CS-8172	OIL SEAL
18	CS-8173	O-RING
19	CS-8600	BUSHING (2)

GEARBOX ASSEMBLY 2 **CS-350/FS-350 SAWS**




1	CS-8100	GEARBOX CASTING	11	CS-8210	MOTOR PLATE
2	CS-8150	LOW SPEED DRIVE GEAR (20/40 RPM)	12	CS-8220	OIL FILLER PLUG
	CS-8152	HIGH SPEED DRIVE GEAR (30/60 RPM)	13	CS-8221	SIGHT LEVEL GAUGE
3	CS-8151	LOW SPEED DRIVEN GEAR (20/40 RPM)	14	V20-2142	1/4 x 7/8 KEY (2)
	CS-8153	HIGH SPEED DRIVEN GEAR (30/60 RPM)	15	X-116	BACK COVER
4	CS-8155	WORM SHAFT	16	X-124	BACK COVER SHIM
5	CS-8156	LARGE BEARING ASSEMBLY	17	X-133	SMALL BEARING ASSEMBLY
6	CS-8157	INTERNAL BEARING RETAINER	18		3/8-16 x 7/8 HHCS (4)
7	CS-8170	RETAINING RING	19		1/4-20 x 1 1/4 SHCS (4)
8		1.25 x 1.75 ARBOR SHIM	20		1/2-13 x 1 1/4 HHCS
9	CS-8174	O-RING	21		1/2-13 x 1 1/2 SHCS (4)
10	CS-8205A	3/1.5 HP 2 SPEED MOTOR-208/230V	22		5/8-11 x 1 1/2 SHCS (4)
	CS-8205B	3/1.5 HP 2 SPEED MOTOR-460V			

SQUARING THE VISE CIRCULAR SAWS



1. Remove the saw blade and replace it with a plate similar to the one shown below. The critical dimensions for making this plate are those for the hole diameter and the flatness and parallelism.
2. The vise alignment may be adjusted by loosening the two vise retaining bolts. Once the vise jaws are square with the test plate as shown above, re-tighten the vise retaining bolts. Re-insert the rubber plugs over the retaining bolts to keep parts from 'catching' as stock feeds across the vise support.

figure 6-2
TEST PLATE (REPLACES BLADE)



SAW VISE CYLINDER REPLACEMENT




figure 6-3

TO REMOVE THE VISE CYLINDER:

1. Turn the electrical power off and remove the air supply to the saw.
2. Remove the handwheel nut, handwheel, key, and air lines from the vise.
3. Remove the 1/4-20 x 3 1/2" cap screws from inside the front vise jaw.
4. Rotate the vise cylinder counter-clockwise to unscrew the cylinder from the vise screw.

TO REPLACE THE VISE CYLINDER:

1. Make sure the cylinder rod is extending fully out of the front of the vise cylinder (port side).
2. Make sure the vise jaws are centered on the vise support.
3. Slide the rod wiper onto the cylinder rod as shown, up to the shoulder on the rod.
4. Screw the vise cylinder clockwise onto the vise screw until it makes contact with the vise jaw - make sure the ports are on the bottom of the cylinder.
5. Check to see that the vise jaws are still centered, and replace the 1/4-20 x 3 1/2 cap screws to connect the cylinder to the vise jaw.
6. Re-attach the air lines to the cylinder ports and turn the air supply back on. Check the vise operation to make sure the vise operates correctly. Reverse the lines if necessary.
7. If everything checks out correctly, remount the handwheel. The saw is again ready for operation.

VISE SCREW RETAINER REPLACEMENT




figure 6-4

1. Open the vise to allow access to the backside of the front vise jaw. Remove the two 1/4-20 x 3 1/2 cap screws that attach either the vise adapter (manual vise) or the vise cylinder (air vise) to the vise jaw.
2. Remove the handwheel and unscrew the vise adapter or vise cylinder (turn counter-clockwise).
3. Loosen the socket head screw in the vise collar - it may be necessary to rotate the vise screw to align the screw with the relief in the retainer block.
4. Replace the handwheel and key. It should not be necessary to tighten the nut. Turn the handwheel counter clockwise until the rear vise jaw is off the screw. Pull the vise screw and front jaw off and set them aside.
5. Remove the two vise retaining bolts. Replace the retainer block, making sure that the top surface of the block is flush with the cutting surface of the vise support casting. Production variations may make it necessary to shim under the retaining block for proper alignment.
6. Reverse steps 1-4 to reassemble the vise. Check the vise alignment. If necessary, re-align the vise as shown in the section on 'Squaring the Vise' (page 6.1).

SPINDLE REPLACEMENT FA-350 SAWS




figure 6.5

1. Disconnect power to the saw.
2. Remove the blade guards, belt guard, drive belts, driven pulley, and pulley spacer.
3. Remove the socket head cap screw located in the bottom of the head casting under the spindle.
4. Using a rubber mallet, drive the old spindle assembly out of the casting, toward the blade flange. The right side bearing may stay in place when the spindle comes out - if this happens, finish removing the spindle, then drive the bearing out toward the belt guard side of the casting. NOTE: the belt guard back plate may need to be removed for this step.
5. Slide the new spindle in from the blade side of the casting. DO NOT USE EXCESSIVE FORCE. Be careful to align the hole in the center bearing spacer with the hole in the bottom of the head casting. When the holes align, replace the cap screw in the casting.
6. Replace the parts removed in step 2. Be careful to properly tighten the drive belts (see page 1.4 for details)

CHANGING THE DRIVE MOTOR FS-350 SAWS





figure 6.6

1. Disconnect the power and open the wiring box on the side of the motor. Disconnect the wiring and remove the cable and fitting from the old motor.
2. Drain the gearbox by removing the drain plug on the right side of the casting. If it is not time to change the gearbox oil, it may be strained and reused. Refer to page 1.2 for the recommended change intervals.
3. Loosen the four bolts that hold the motor plate to the gearbox, and remove the motor/plate combination.
4. Separate the motor plate from the motor by removing the four bolts on the inside of the motor plate. It may be necessary to pry slightly to break the seal between the motor and plate.
5. Remove the bolt that holds the drive gear on the motor shaft and slide the gear off the shaft. Do not lose the key that may come off with the gear.
6. Reverse steps 1-5 to reassemble the saw.

NOTES:

- a) Be sure to use removable 'Loctite' on the bolt that secures the drive gear to the motor shaft.
- b) Scrape away the silicone sealer on the mating face of the motor and plate. Use fresh sealer at assembly to stop leaks.
- c) Make sure the O-ring is securely in the groove on the motor plate face that mates to the gear box. If necessary, use a dab of grease to keep it in place.
- d) Re-wire the motor according to the schematics included in section 8 of this manual.

CHANGING BLADE SPEEDS FA-350 SAWS



1. Loosen the four motor mounting bolts and the two motor plate bolts.
2. Slide the motor towards the blade until the belts can be removed.
3. Remove the three bushing bolts from the drive pulley and slide the pulley off of the motor shaft.
4. Slide the new pulley on the motor shaft and tighten the bushing bolts.
5. Install the new drive belts.
6. The belts are retensioned by pushing the motor away from the blade until a slight thumb pressure on the center of the belts produces a 5/8" deflection and then tightening the motor plate bolts.
7. Re-tighten the motor mounting bolts.

CHANGING THE DRIVE GEARS FS-350 SAWS




figure 6.8

1. Drain the gearbox by removing the plug on the right side of the casting. If it is not time to change the gearbox oil, it may be strained and reused. Refer to page 1.2 for the recommended oil change intervals.
2. Loosen the four bolts that hold the motor plate to the gearbox and separate the motor/plate from the gearbox.
3. Remove the bolt that holds the drive gear on the motor shaft and slide the gear off the shaft. Do not lose the key that may come off with the gear.
4. The driven gear is removed by removing the retaining ring from the worm shaft and sliding the gear off. Be careful not to lose the arbor space that may be used with the gear.
5. Reverse steps 2-5 to re-assemble the gear case. Only tighten the four bolts through the motor plate finger-tight with the motor/plate combination at the bottom of the mounting holes. Refill the gearbox with oil and start the motor on low speed. Using a prybar, pry up on the motor until gear noise is heard. Tap the motor down until the noise stops. Finish tightening the motor mounting bolts.

NOTES:

- a) Be sure to use removable 'Loctite' on the bolt that secures the drive gear to the motor shaft.
- b) Make sure the O-ring is securely in the groove on the motor plate face that mates to the gearbox. If necessary, use a dab of grease to keep it in place.

PARTS COUNTER CHANGING AUTOMATIC SAWS





figure 6.9


1. Loosen the screws to open the counter enclosure.
2. Remove the wiring from the terminal strips. Note the position of the wires in the strip.
3. The counter is held against the panel by a wire spring. Release the spring by pushing up on the spring on each side of the counter. Pull the spring ends out of the counter to allow the counter to pass through the panel.
4. Set the switches on the sides of the counter (shown above). The switch numbers are molded into the counter case. Switches 1, 2, 9, 10, and 11 should be set 'on'—all others should be set 'off'. Set the power switch for 115V operation.
5. Remove the spring from the new counter and insert the counter through the panel opening. Re-install the spring in the counter and flip the spring against the panel, pushing it down to tension the counter against the panel.
6. Re-connect the wiring (ref. page 8.13), close the panel, and tighten the screws.

HEAD FEED RESERVOIR ASSEMBLY CIRCULAR SAWS



- | | | |
|----|------------|--|
| 1 | CS-4043 | DOUBLE P.O. CHECK VALVE: SUN #CKCC-XAN-YEB |
| 2 | V20-7114-1 | VALVE MOUNTING PLATE |
| 3 | V20-7115 | AIR/OIL RESERVOIR: LUBE DEVICES #A/OR 1030-2 (2) |
| 4 | V20-8019 | 3/8 NPT x 1/2 HOSE ELBOW: ALKON #AQ69-PS-8x6 (3) |
| 5 | V20-8028 | 1/4 NPT x 3/8 HOSE ELBOW: ALKON #AQ69-PS-6x4 (2) |
| 6 | V20-8029 | 1/4 NPT x 1/2 HOSE ELBOW: ALKON #AQ69-PS-8x4 (2) |
| 7 | | 1/2 PLASTIC TUBE x 12" LG (REF #5) |
| 8 | | 1/2 PLASTIC TUBE x 12" LG (REF #12) |
| 9 | | 1/4-20 x 3/4 SHCS (4) |
| 10 | | 5/16-18 x 1 3/4 SHCS (2) |
| 11 | | 5/16-18 HEX NUT (2) |
| 12 | | 5/16 FLAT WASHER (2) |
| 13 | V20-8019 | 3/8 NPT x 1/2 HOSE ELBOW: ALKON #AQ69-PS-8x6 (FA-350 SAWS) |
| | V20-8032 | 3/8 NPT x 1/4 HOSE ELBOW: ALKON #AQ69-PS-4x6 (FS-350 SAWS) |


CARRIAGE FEED RESERVOIR SUB-ASSEMBLY



1	C-11	SHUTOFF VALVE: PARKER #V402P-4-4 (2)
2	CS-4055	VALVE MOUNTING PLATE
3	CS-4056	AIR/OIL RESERVOIR: LUBE DEVICES #A/OR 2150-4 (2)
4	V20-8028	1/4 NPT x 3/8 HOSE ELBOW: ALKON #AQ69-PS-6x4 (2)
5	V20-8030	1/2 NPT x 1/2 HOSE ELBOW: ALKON #AQ69-PS-8x8 (2)
6		1/4-20 x 3/4 SOCKET HEAD CAP SCREW (4)

EFFECTIVE FOR MACHINES BUILT AFTER S/N 241

PNEUMATIC VALVE PARTS CS-350PV / FS-350PV




- | | | |
|---|------------|---|
| 1 | CS-4020-1 | AIR VALVE |
| 2 | CS-5054-1 | LIMIT SWITCH TRIGGER |
| 3 | V20-7122-1 | MUFFLER: PARKER #EM12 (2) |
| 4 | V20-8027 | 1/8 NPT x 3/8 HOSE ELBOW:
ALKON #AQ69-PS-6x2 |
| 5 | | 10-24UNC x 1 1/2 SOCKET HEAD CAP SCREW (2) |
| 6 | | 1/4-20UNC x 3/8 SOCKET HEAD CAP SCREW |
| 7 | | #10 FLAT WASHER (12) - 6 LOCATED BETWEEN
THE VALVE AND THE HEAD FRAME ON EACH
MOUNTING SCREW (ITEM 5) |

NOTE: SOME EARLY SAWS USED 1/4" TUBING, THE
FITTING FOR THIS TUBING IS:

- | | | |
|---|----------|---|
| 4 | V20-8002 | 1/8 NPT x 1/4 HOSE ELBOW:
ALKON #AQ69-PS-4x2 |
|---|----------|---|

VALVE MANIFOLD ASSEMBLY SEMI-AUTOMATIC SAWS




VALVE WIRING

WIRE NUT	
16 (ORANGE)	1SOL. BLACK LEAD
14 (RED)	2SOL. BLACK LEAD
17 (BLUE)	3SOL. BLACK LEAD
19 (BLACK)	4SOL. BLACK LEAD
X2 (WHITE)	ALL WHITE LEADS
GROUND (GREEN)	ALL GREEN LEADS


- | | | |
|----|----------|--|
| 1 | CS-4035 | VALVE MANIFOLD WITH MUFFLERS |
| 1A | CS-4035A | NUMATICS #L12BB5520 SOLENOID VALVE |
| 1B | CS-4035B | NUMATICS #L12BB6520 SOLENOID VALVE |
| 1C | CS-4035C | NUMATICS #8-28 1/4 NPT MUFFLER |
| 1D | CS-4035D | NUMATICS #230-366-SP 3 PIN PLUG W/LITE AND CORD |
| 2 | CS-4044 | VALVE MOUNTING PLATE |
| 3 | CS-4045 | M4 x 12 MM PHMS: MC MASTER CARR #90353A214 (2) |
| 4 | CS-5056A | 6 COND 20AWG CABLE: ALPHA #5056C (8') |
| 5 | HA-15303 | JUNCTION BOX: APPLETON #JIC-2 |
| 6 | V20-8001 | 1/4 NPT x 1/4 HOSE ELBOW: ALKON #AQ69-PS-4X4 (2) |
| 7 | V20-8026 | 1/4 NPT x 3/8 HOSE CONN: ALKON #AQ68-P-6X4 |
| 8 | V20-8028 | 1/4 NPT x 3/8 HOSE ELBOW: ALKON #AQ69-PS-6X4 (2) |
| 9 | | REMKE #RSR-9106 CORD GRIP (5) |
| 10 | | |
| 11 | | |
| 12 | | #8-32 x 3/8 SELF-TAPPING SCREW (2) |

VALVE MANIFOLD ASSEMBLY AUTOMATIC SAWS




- | | | |
|----|----------|---|
| 1 | CS-4036 | VALVE MANIFOLD WITH MUFFLERS |
| 1A | CS-4035A | NUMATICS #L12885520 SOLENOID VALVE |
| 1B | CS-4035B | NUMATICS #L12886520 SOLENOID VALVE |
| 1C | CS-4035C | NUMATICS #8-28 1/4 NPT MUFFLER |
| 1D | CS-4035D | NUMATICS #230-366-SP 3 PIN PLUG W/LITE AND CORD |
| 2 | CS-4044 | VALVE MOUNTING PLATE |
| 3 | CS-4045 | M4 x 12 MM PHMS: MC MASTER CARR #90353A214 (2) |
| 4 | H3-3230 | JUNCTION BOX: HOFFMAN #A604SC |
| 5 | H3-5037 | 10 COND 18AWG CABLE: ALPHA #5070C (8') |
| 6 | | |
| 7 | V20-8026 | 1/4 NPT x 3/8 HOSE CONN: ALKON #AQ68-P-6X4 (8) |
| 8 | V20-8028 | 1/4 NPT x 3/8 HOSE ELBOW: ALKON #AQ69-PS-6X4 |
| 9 | | |
| 10 | | REMKE #RSR-106 CORD GRIP (8) |
| 11 | | REMKE #RSR-9106 CORD GRIP |
| 12 | | |
| 13 | | |
| 14 | | #8-32 x 3/8 SELF-TAPPING SCREW (2) |

FILTER/REGULATOR/LUBRICATOR ASSEMBLY



1	CS-4013A	PARKER #PS109 MOUNTING BRACKET (2)
2	CS-4013B	PARKER #16L118C LUBRICATOR
3	CS-4013B1	PARKER #PS125 BOWL KIT
4	CS-4013C	PARKER #11F11EA OIL REMOVAL FILTER
5	CS-4013C1	PARKER #PS105 BOWL KIT (2)
6		
7	CS-4013D	PARKER #06E11A13AA FILTER/REGULATOR
8		
9	CS-4013E	PARKER #P781642 0-160 PSI 2" DIAL GAUGE
CS-4013REK FILTER ELEMENT KIT-INCLUDES THE FOLLOWING:		
		PARKER #PS101 FILTER ELEMENT
		PARKER #PS146 OIL REMOVAL FILTER ELEMENT


PNEUMATIC DIAGRAM CA-350PV/CS-350PV FA-350PV/FS-350PV



- | | | |
|---|------------|--|
| 1 | CS-4013 | FILTER/REGULATOR/LUBRICATOR |
| 2 | CS-4022-1 | CAM-OPERATED VALVE: WABCO #GB15002-0955 |
| 3 | V20-7122-1 | EXHAUST MUFFLER: PARKER #EM12 |
| 4 | CS-2316 | VISE CYLINDER: 5" BORE x 3/8" STROKE |
| 5 | V20-7117B | PRESSURE REDUCING VALVE: PARKER #14R113F |
| 6 | V20-7117A | PRESSURE GAUGE: PARKER #77413 |


NOTE: SAWS WITH SERIAL NUMBERS BELOW 104 USE PRESSURE GAUGE P/N CS-4025
INSTEAD OF P/N V20-7117A

HEAD LIFT CYLINDER FITTINGS CIRCULAR SAWS



- | | | |
|---|----------|--|
| 1 | CS-4014 | HEAD LIFT CYLINDER (REF) |
| 2 | CS-4046 | AIR VENT: WEATHERHEAD #705 |
| 3 | CS-4047 | STREET TEE: WEATHERHEAD #3750x6 |
| 4 | CS-4048 | 3/8NPT x 1/8NPT BUSHING: WEATHERHEAD #3220x6x2 |
| 5 | V20-8019 | 3/8NPT x 1/2 HOSE ELBOW: ALKON #AQ69-PS-8x6 |
| 6 | V20-8032 | 3/8NPT x 1/4 HOSE ELBOW: ALKON #AQ69-PS-4x6 |


PNEUMATIC DIAGRAM FA-350SA/FS-350SA



- | | | |
|----|-----------|--|
| 1 | CS-4013-1 | FILTER/REGULATOR/LUBRICATOR ASSEMBLY |
| 2 | CS-4035 | VALVE MANIFOLD ASSEMBLY |
| 3 | CS-2316 | VISE CYLINDER ASSEMBLY: 5" BORE x 3/8" STROKE
x 1 1/2" THRU ROD |
| 4 | V20-7117A | PRESSURE GAUGE: PARKER #P77413 (OPTION) |
| 5 | V20-7117B | PRESSURE REGULATOR: PARKER #04R113F (OPTION) |
| 6 | V20-7115 | AIR/OIL RESERVOIR: LUBE DEVICES #1030-2 (2) |
| 7 | CS-4043 | DOUBLE P. O. CHECK VALVE: PARKER #CDP1010A206P |
| 8 | CS-4017-1 | FLOW CONTROL VALVE: DELTROL #EDF-25B |
| 9 | CS-4014-1 | PNEUMATIC CYL: 2 1/2" BORE x 3 3/4" STROKE
x 1" ROD-NFPA STYLE MX-3 |
| 10 | CS-4046 | AIR VENT: WEATHERHEAD #705 |

EFFECTIVE WITH SERIAL NO. 240

7.10



PNEUMATIC DIAGRAM FA-350A/FS-350A


PARTS LIST
PNEUMATIC DIAGRAM
FA-350A/FS-350A

1	CS-4013-1	FILTER/REGULATOR/LUBRICATOR ASSEMBLY
2	CS-4036	VALVE MANIFOLD ASSEMBLY
3	CS-2316	WISE CYLINDER ASSEMBLY: 5" BORE x 3/8" STROKE x 1 1/2" THRU ROD
4	V20-7117A	PRESSURE GAUGE: PARKER #P77413 (OPTION)
5	V20-7117B	PRESSURE REGULATOR: PARKER #O4R113F (OPTION)
6	V20-7115	AIR/OIL RESERVOIR: LUBE DEVICES #A/OR1030-2
7	CS-4043	DOUBLE P. O. CHECK VALVE: PARKER #CDP101A206P
8	CS-4017-1	FLOW CONTROL VALVE: DELTROL #EDF-25B
9	CS-4014-1	PNEUMATIC CYL: 2 1/2 BORE x 3 3/4 STROKE x 1 ROD - NFPA STYLE MX-3
10	CS-4034	PNEUMATIC CYL: 2 1/2 BORE x 18 STROKE x 1 ROD - NFPA STYLE MX-3
11	CS-4016-1	PNEUMATIC CYL: 3 1/4 BORE x 1/2 STROKE x 1 ROD - NFPA STYLE MF-1
12	CS-7515-1	PNEUMATIC CYL: HUMPHREY #5-D-1/2: 1 1/2 BORE x 1/2 STROKE x 7/16 ROD (OPTION)
13	CS-4046	AIR VENT: WEATHERHEAD #705
14	CS-4056	AIR/OIL RESERVOIR: LUBE DEVICES #A/OR2150-4

NOTES


ELECTRICAL CONTROLS CA-350/CA-350PV CS-350/CS-350PV

EFFECTIVE WITH S/N 382 (JUNE, 1992)




1	9A-5040A	ALLEN-BRADLEY #100-A24ND3 CONTACTOR (120V)
2	9A-5040B	ALLEN-BRADLEY #592-JOV16 OVERLOAD RELAY
3	9A-5040C	ALLEN-BRADLEY #800E-MT4 MUSHROOM HEAD OPERATOR
4	9A-5040D	ALLEN-BRADLEY #800E-XL01 1-N.C. CONTACT BLOCK
5		
6	9A-5040F	ALLEN-BRADLEY #800E-F3 GREEN PB OPERATOR
7	9A-5040G	ALLEN-BRADLEY #800E-XL10 1-N.O. CONTACT BLOCK
8		
9	9A-5040J	HOFFMAN #A1212CH CLAMP COVER ENCLOSURE
10	9A-5040K	HOFFMAN #A12P12 ENCLOSURE PANEL
11	CS-5019	DONGAN #HC-0250-44 FKPS2S TRANSFORMER
12		ALLEN-BRADLEY #1492-H1 TERMINAL BLOCK
13		ALLEN-BRADLEY #1492-N36 END BARRIER
14		ALLEN-BRADLEY #1492-N42 INSULATED JUMPER
15		ALLEN-BRADLEY #1492-N2 RETAINING CLIP
16		ALLEN-BRADLEY #1492-N1 MOUNTING CHANNELx2 1/4"
17	CS-5064-1	MOTOR SPEED SWITCH ASSEMBLY (CS-350 SAWS ONLY: INCLUDES CS-5064-1A-1C BELOW)
	CS-5064-1A	MOTOR SPEED SWITCH LEGEND PLATE
	CS-5064-1B	MOTOR SPEED SWITCH OPERATOR HANDLE
	CS-5064-1C	MOTOR SPEED SWITCH CONTACT BLOCK
18		
19		
20		
21		
22		
23	9A-5040N	ALLEN-BRADLEY #800E-SM21 2 POS SS OPERATOR
24	9A-5040R	SWITCH BOX OVERLAY

SWITCH PANEL ASSY **FA-350/FA-350PV** **FS-350/FS-350PV**




ON SAWS WITHOUT THIS SWITCH, USE ITEM #10




- | | | |
|----|---------|--|
| 1 | CS-5047 | 3 POS ENCLOSURE- HOFFMAN #E-3PBGX |
| 2 | CS-5022 | SWITCH OPERATOR- SQUARE D #9001-D1C1R |
| 3 | CS-5024 | PILOT LIGHT BODY- SQUARE D #9001-D1V1Y |
| 4 | CS-5025 | LIGHT MODULE- SQUARE D #9001-DTSC |
| 5 | CS-5053 | CONTACT BLOCK- SQUARE D #9001-DA02 |
| 6 | CS-8207 | PANEL OVERLAY- FS-350M/PV |
| 7 | CS-5031 | LAMP- GE #1866 |
| 8 | CS-5028 | CONTACT BLOCK- SQUARE D #9001-DA10 |
| 9 | CS-5034 | SWITCH OPERATOR- SQUARE D #9001-D1G2S |
| 10 | CS-5062 | CLOSING PLATE- SQUARE D #9001-Z33 |

FA-350SA/FS-350SA SWITCH PANEL ASSEMBLY




- | | | |
|----|---------|---|
| 1 | CS-5080 | SWITCH ENCLOSURE: HOFFMAN #E-9PBGX |
| 2 | CS-5082 | SWITCH ENCLOSURE OVERLAY |
| 3 | CS-5022 | SQUARE D #9001-D1C1R MUSHROOM HEAD SW. OPER. |
| 4 | CS-5027 | SQUARE D #9001-DA01 N.C. CONTACT BLOCK |
| 5 | CS-5029 | SQUARE D #9001-D1M3U DUAL FUNCTION OPERATOR |
| 6 | CS-5030 | SQUARE D #9001-DTSC11 LIGHT MOD. (INCL. 1LT) |
| 7 | CS-5031 | G.E. #1866 LAMP (2) |
| 8 | CS-5035 | SQUARE D #9001-D1A3R RED PUSH BUTTON OPERATOR |
| 9 | CS-5028 | SQUARE D #9001-DA10 N.O. CONTACT BLOCK (2) |
| 10 | CS-5032 | SQUARE D #9001-D1Y1G GREEN PUSH BUTTON OPER. |
| 11 | CS-5030 | SQUARE D #9001-DTSC11 LIGHT MOD. (INCL. 2LT) |
| 12 | CS-5033 | SQUARE D #9001-D1G4S 3 POS. MOM. SWITCH OPER. (2) |
| 13 | CS-5037 | SQUARE D #9001-DA20 2-N.O. CONTACT BLOCK (2) |
| 14 | CS-5065 | SQUARE D #9001-D1A1U GREEN PUSH BUTTON OPER. (FA-350SA) |
| 15 | CS-5075 | SECOND CYCLE START OVERLAY (FA-350SA) |

CONSOLE ASSEMBLY
FA-350A / FS-350A



- 1 AB-17130 PRESET COUNTER: DURANT #45610-400
- 2 CS-1415 CONSOLE WELDMENT
- 3 CS-1415H CONTROLLER MOUNTING SPAR
- 4 CS-1416 CONSOLE OVERLAY (FA-350A)
- CS-1416S CONSOLE OVERLAY (FS-350A)
- 5 CS-1417 FOAM SEAL TAPE (66")
- 6 CS-5022 MUSHROOM HD SW. OPERATOR: SQUARE D #9001-D1C1R
- 7 CS-5024 AMBER PILOT LIGHT BODY: SQUARE D #9001-D1V1Y
- 8 CS-5025 LIGHT MODULE: SQUARE D #9001-DTSC
- 9 CS-5027 N.C. CONTACT BLOCK: SQUARE D #9001-DA01
- 10 CS-5028 N.O. CONTACT BLOCK: SQUARE D #9001-DA10 (2)
- 11 CS-5029 DUAL FUNCTION SW. OPER.: SQUARE D #9001-D1H3U
- 12 CS-5030 LIGHT MODULE: SQUARE D #9001-DTSC11 (2)
- 13 CS-5031 LIGHT BULB: GE #1866 (3)
- 14 CS-5032 GREEN LIGHTED SW. OPER.: SQUARE D #9001-D1Y1G
- 15 CS-5033 3-POS. MOMENTARY SW. OPER.: SQUARE D #9001-D1G4S (4)
- 16 CS-5035 RED PUSHBUTTON SW. OPER.: SQUARE D #9001-D1A3R
- 17 CS-5036 3-POS. MAINTAINED SW. OPER.: SQ. D #9001-D1G3S
- 18 CS-5037 2-N.O. CONTACT BLOCK: SQUARE D #9001-DA20 (5)
- 19 CS-5042 PROGRAMMABLE CONTROLLER: OMRON #C40K-COR-A
- 20 CS-5044 EEPROM CHIP: OMRON #90M-H
- 21 CS-5045 2-N.C. CONTACT BLOCK: SQUARE D #9001-DB02
- 22 CS-5057 LIMIT SW.: OMRON D4C-1603
- 23 CS-5065 GREEN PUSHBUTTON SW. OPER.: SQ. D #9001-D1A1U
- 24 CS-5084 5-POS. MAINTAINED SW. OPER.: SQ. D #9003-KA81A
- 25 CS-5085 5-POS. CONTACT BLOCK: SQUARE D #9003-K2D0040A
- 26 H3-5023 VARISTOR: CKE #Z150LA20A (2)
- 27 1/2 NPT CORD GRIP: REMKE #RSR-9106
- 28 1/2 NPT CORD GRIP: REMKE #RSR-9110
- 29 1/2" CONDUIT SEALING RING (2)
- 30 1/2" CONDUIT LOCKNUT (2)
- 31 #6-32 x 1/2 THREAD CUTTING SCREW (3)
- 32 #10-24 x 1/2 THREAD CUTTING SCREW (4)

ELECTRICAL ENCLOSURE PANEL 'F' SERIES CIRCULAR SAWS



1M	CS-5020A	MOTOR CONTACTOR: SQUARE D #8502 PE5.22E
1DISC	CS-5020D	DISCONNECT SWITCH BODY: STROMBERG #0ETL-NF30
		DISC. SWITCH HANDLE: STROMBERG #0ETLZX 44/90
	CS-5020F	FUSE BLOCK: MARATHON #6M30A3SP
1XFMR	CS-5019	TRANSFORMER: 250VA, 440/220/208V PRI-120V SEC
1MB	CS-7150C	MOTOR BRAKE: SQUARE D #8922 EMB-20 440V/120V
	CS-7150B	MOTOR BRAKE: SQUARE D #8922 EMB-36 220V/120V
2M	CS-5020A	MOTOR CONTACTOR: SQUARE D #8502 PE5.22E
1MOL	CS-5020B1	OVERLOAD RELAY: SQUARE D #9065-TE3.7 (440V)
	CS-5020B2	OVERLOAD RELAY: SQUARE D #9065-TE8 (220/208V)
1-3FU		BUSSMAN #KTK-R-30 FUSE (208/230V)
1-3FU		BUSSMAN #KTK-R-12 FUSE (460V)
4FU		BUSSMAN #FNM-2 1/2 FUSE
5FU		BUSSMAN #FNM-1 1/4 FUSE
8FU		BUSSMAN #AGC-2 FUSE
9FU		BUSSMAN #AGC-3/10 FUSE
10-11FU	CS-7151	BUSSMAN #FWH-15 SEMICONDUCTOR FUSE (440V)
10-11FU	CS-7151B	BUSSMAN #FWH-35 SEMICONDUCTOR FUSE (208/220V)
1-3CR	CS-5011	4PDT RELAY: OMRON #HY4US-AC120
1-2TR	CS-5013-1	TIMER: OMRON #H3G-8C-AC1105S
	CS-5070	CIRCUIT BOARD (SEMI-AUTOMATIC SAWS ONLY)

1MB, 2M, 7FU, AND 8FU ARE ONLY USED ON MACHINES WITH THE
ELECTRONIC MOTOR BRAKE OPTION

FUSES 8FU AND 9FU ARE ONLY USED ON AUTOMATIC SAWS

FUSES 10FU & 11FU ARE SHOWN AS 7FU & 8FU ON SEMI-AUTOMATIC SAWS

1-3CR AND 1-2TR ARE ONLY USED ON SEMI-AUTOMATIC SAWS
(FA-350SA AND FS-350SA)

CHANGING OPERATING VOLTAGES
CA-350/CS-350 SAWS

To change between 208/230 and 460 volts, you must change the motor wiring (shown on the motor nameplate), the overload heater elements (shown on page 8.25), and the transformer wiring (shown on a decal on the transformer and on page 8.9). It is not necessary to change the transformer fusing

NOTE: On CS-350 saws, the motor itself must be changed. See page 6.5 for directions.

CHANGING OPERATING VOLTAGES

If it should become necessary to change the operating voltage of your new KALAMAZOO circular saw, please note the following:

1. TURN OFF POWER AT THE SUPPLY!

2. POWER FUSES (1-3FU): Whenever voltages are changed, the fuse values should be adjusted accordingly. Improper fusing can lead to nuisance tripping or unprotected electrics.

208V or 230V machines use Bussman KTK-R-30 fuses (or equal)
460V machines use Bussman KTK-R-12 fuses (or equal)
575V machines use Bussman KTK-R-10 fuses (FA-350 saws only)

3. TRANSFORMER (1XFMR): The standard transformer in your saw has a 'tri-voltage' primary. It can operate on 208V, 230V, or 460V by simply changing the primary leads. The four leads or terminals (depending on the transformer) are marked H1, H2, H3, and H4 and are at the top of the transformer. Proper connections are shown on page 8.9 and on the transformer nameplate. If there is any discrepancy between the manual and the nameplate, ALWAYS follow the nameplate instructions. If the transformer has primary leads, any unused leads should be insulated (separately) to prevent them from making electrical contact with the enclosure.

The secondary leads (X1 and X2) do not change for different voltages.

4. OVERLOAD RELAY (1MOL): Depending on the operating voltage, the following overload relays are used:

460V and 575V: KALAMAZOO P/N CS-5020B1 (Marked TE3.7)
208V and 230V: KALAMAZOO P/N CS-5020B2 (Marked TE8)

Changing between 208/230V and 460/575V requires a change of overload relays. Changing between 208V and 230V or between 460V and 575V requires only an adjustment of the trip current setting. Those settings are as follows:

FA-350 saws
208V: 9.5
230V: 9.0
460V: 4.5
575V: 3.7

FS-350 saws
208V: 8.0
230V: 8.0
460V: 4.0


not available at this voltage

Correct adjustment of the trip current setting will prevent nuisance tripping of the overload while protecting the motor.

To replace the overload relay, undo the wires from the bottom two rows of terminals on the overload, then loosen the four lower contactor screws (see illustration on page 8.8). The relay will drop away from the contactor. When installing the new contactor, make sure all screws are tight.

CHANGING OPERATING VOLTAGES (continued)

If the overload relay is changed, the blue 'Reset' button must be pushed before the motor will operate.




5. **ELECTRONIC MOTOR BRAKE (1MB):** If your machine has a motor brake, it must be changed if you are changing between 460V and 208/230V. No changes are required between 208V and 230V. Consult the factory for help in making this change.

CHANGING OPERATING VOLTAGES (continued)

6. CS-350/FS-350 SAWS: To change these saws between 208V and 230V operation, just change the transformer primary connection.


To change between 208/230V and 460v operation, you must change the power fuses, overload relay, and transformer primary connections, and set the overload trip current as explained in steps 1-4 above. In addition, the drive motor must be changed. Refer to page 6.5 for details.

TRANSFORMER CONNECTIONS



DONGAN #HC-0250-44 TRANSFORMER

208V OPERATION: CONNECT TO H1 AND H2
230V OPERATION: CONNECT TO H1 AND H3
460V OPERATION: CONNECT TO H1 AND H4



MICRON #V250MBT13XK TRANSFORMER

208V OPERATION: CONNECT TO H3 AND H4
230V OPERATION: CONNECT TO H2 AND H4
460V OPERATION: CONNECT TO H1 AND H4

CHANGING INDICATOR LAMPS FA-350/FS-350 SAWS

REF: 'Blade On' light (M and PV models), 'Cycle Start' light (SA and A saws), 'Blade On' light (SA and A saws), and the 'Power On' light (A saws)

1. Turn off the power at the disconnect switch.
2. Unscrew the cover to the switch enclosure.
3. In the middle of one side of the contact block is a plastic loop with a metal wire. A screwdriver inserted into the loop and pried down will lift the wire and separate the contact block and lamp body from the switch operator.
4. The lamp should be visible on the front of the light module. It is removed by pushing down and rotating counter-clockwise.
5. The new bulb is inserted and turned clockwise.
6. The contact block/light module is reattached by lining up the side wires with the grooves in the switch operator or lens and pushing it into place. You will feel the light module snap into place.
7. Turn the power back on and test the light, then close up the switch enclosure.

SWITCH OPERATOR/CONTACT BLOCK REPLACEMENT

If it should become necessary to replace either the contact block or switch operator, they are both accessed and removed as described in steps 1-3 above. To remove the switch operator from the panel, loosen the plastic nut and slide the operator through the front of the panel. When replacing the operator, take note of the tab on one side. This tab should fit into the notch in the panel and overlay to prevent switch rotation.

The contact block is re-installed as above.

MOTOR CONTACTOR MAINTENANCE FA-350/FS-350 SAWS


INSTALLATION AND REMOVAL

To remove a contactor from the DIN rail, insert a screwdriver into the red clip at the top back of the contactor and pry downward to lift the clip. This will loosen the contactor from the rail. To replace the contactor, place the contactor over the top lip of the DIN rail and push down while rotating the bottom of the contactor down toward the rail.




COIL REPLACEMENT


The first step in replacing the contactor coil is removing the auxiliary contact block. Depress the red lever shown below and slide the block up. To replace, slip the tabs on the back of the block into the holes on the contactor face and push down.



To remove the coil, use a screwdriver to release the two metal clips as shown below and lift the housing assembly. Depress the coil and slide it down. Replace with Square D P/N 9998PD2C110A.



WIRE NUMBERS AND COLORS ARE REFERENCED ON THE ELECTRICAL SCHEMATICS





NOTE: A VARISTOR (P/N H3-5023) IS CONNECTED BETWEEN THE AC INPUT TERMINALS

LOGIC CONTROLLER WIRING


FA-350A / FS-350A

PARTS COUNTER WIRING **FA-350A/FS-350A**




SWITCH SETTINGS ON SIDE OF COUNTER
SWITCHES 1. 2. 9. 10. 11 SHOULD BE 'ON'
ALL OTHER SWITCHES SHOULD BE 'OFF'

POWER SWITCH SHOULD BE SET FOR 120V




FA-350SA/FS-350SA SWITCH PANEL ASSEMBLY

CONTROL PANEL WIRING
(VIEWED WITH COVER HINGED DOWN)



WIRE COLOR CODE
(WIRE COLOR/STRIPE COLOR(S))

- X2 WHITE
- 1 WHITE/BLACK
- 2 RED/YELLOW
- 3 WHITE/BLACK & RED
- 4 WHITE/BLUE
- 5 WHITE/GRAY
- 6 WHITE/RED
- 8 WHITE/ORANGE
- 13 GRAY
- 14 RED
- 16 ORANGE
- 17 BLUE
- 18 RED/BLACK
- 19 BLACK




NOTE: THIS SWITCH NOT
USED ON FS-350A SAWS.
WIRE #8 NOT USED

WIRE COLOR CODE
25 CONDUCTOR CABLE

25 CONDUCTOR CABLE	
X2	WHITE
1	PINK
2	WHITE W/ORANGE TRACER
3	WHITE W/PURPLE
4	WHITE W/GRAY
20	WHITE W/BLUE
21	WHITE W/BROWN
22	WHITE W/GREEN
23	WHITE W/YELLOW
24	WHITE W/RED
28	WHITE W/BLACK & RED
29	BLACK
30	RED
31	ORANGE
32	BLUE
33	BROWN
34	YELLOW
35	VIOLET
36	GRAY
42	WHITE W/BLACK
GND	GREEN

ELECTRICAL SCHEMATIC CA-350/CA-350PV SAWS WITH MAGNETIC STARTER



EFFECTIVE WITH SERIAL NO. 377




REVISÉD 6/92


ELECTRICAL SCHEMATIC **FA-350M/FA-350PV**

NOTE: INCOMING POWER LEADS
TO BE AWG 10 MINIMUM


1/2" CONDUIT (TRADE SIZE)



ELECTRICAL SCHEMATIC **FS-350M/FS-350PV**



8.20



NOTE - INCOMING POWER LEADS TO
BE AWG 10 MINIMUM


1/2" CONDUIT (TRADE SIZE)

208V
230V
460V
60HZ/3PH

10/SC
1FU
2FU
3FU
208/230V - 30 AMP
460V - 12 AMP

CONNECT TRANSFORMER WIRING
ACCORDING TO NAMEPLATE DIRECTIONS
(460V WIRING SHOWN)


1SS
SPEED SELECT
LOW HIGH



FULL LOAD AMPS			
LEESON MOTORS			
	1725 RPM	850 RPM	
208/230V	7.6	6.9	
460V	3.8	3.5	
BALDOR MOTORS			
0.8 F.L.A.	208/230V		
4.4 F.L.A.	460V		

3 HP, 1725 RPM
1.5 HP, 850 RPM

NOTE: DIFFERENT MOTORS REQUIRED
FOR 230 OR 460V OPERATION



BLADE MOTOR
STARTER
(4, 5, 7)

BLADE ON
(PART OF 2PB SWITCH)

COOLANT PUMP

PIN NUMBERS ON 15 PIN CONNECTOR

CYCLE START RELAY
(9, 13, 14, 15, 20)

BOXED COMPONENTS LOCATED
ON PRINTED CIRCUIT BOARD

HEAD FEED TIMER
(18)

CYCLE END TIMER
(10)

END OF CYCLE RELAY
(11, 15)

END OF CUT RELAY
(13, 16, 19, 20)

HEAD FEED

HEAD RAISE

WISE CLAMP

WISE OPEN


POWER ON LIGHT
(PART OF 4PB)

8.24

ELECTRICAL SCHEMATIC
FS-350SA

EFFECTIVE WITH SERIAL NO. 241

FOR BEST RESULTS, THE SAW SHOULD
HAVE A SEPARATE ELECTRICAL CIRCUIT






EFFECTIVE WITH SERIAL NO. 241

ELECTRICAL SCHEMATIC

FA-350A

NOTES: INCORPORATE POWER LEADS SHOULD BE
AND 10 MINIMUM
1/2" CONDUIT (TRADE SIZE)
FOR BEST RESULTS, THE SAW SHOULD
HAVE A SEPARATE ELECTRICAL CIRCUIT



EFFECTIVE WITH SERIAL NO. 241


ELECTRICAL SCHEMATIC **FS-350A**

3 PHASE ELECTRICAL SCHEMATIC CHIP COLLECTION SYSTEM

NOTE: INCOMING LEADS TO BE AWG 14 MINIMUM
1/2" CONDUIT (TRADE SIZE)

MACHINE SHOULD BE INSTALLED IN ACCORDANCE
WITH THE NATIONAL ELECTRICAL CODE (NEC) AS
WELL AS ANY STATE OR LOCAL CODES THAT APPLY.

FUSED DISCONNECT RECOMMENDED
(INSTALLED BY USER)



1MTR		BALDOR #35J395-672 3HP MOTOR 56C FRAME
1M	9A-220E	ALLEN-BRADLEY #609TU-AAH STARTER (208V)
	9A-220B	ALLEN-BRADLEY #609TU-AAA STARTER (230V)
	9A-220C	ALLEN-BRADLEY #609TU-AAB STARTER (460V)
1MOL		ALLEN-BRADLEY #W47 HEATER ELEMENT (208/230V)
		ALLEN-BRADLEY #W40 HEATER ELEMENT (460V)

OVERLOAD HEATER ELEMENTS
ALLEN-BRADLEY 609TU SWITCHES
SAWS WITH LEESON MOTORS

MODEL(S)	VOLTAGE	HEATER(S)	FUSE SIZE AT SAW DISCONNECT	FUSE SIZE FOR WALL DISCONNECT
CS-350 (ALL)	208/230	W50	NONE	9 AMP
	460	W42	NONE	5 AMP
CA-350 (ALL)	208	W52	NONE	10 AMP
	230	W51	NONE	10 AMP
	460	W43	NONE	5 AMP

SAWS WITH BALDOR MOTORS

CS-350 (ALL)	208/230	W51	NONE	10 AMP
	460	W42	NONE	6 AMP
CA-350 (ALL)	208	W52	NONE	10 AMP
	230	W51	NONE	10 AMP
	460	W43	NONE	5 AMP

OVERLOAD HEATER ELEMENTS
SQUARE D CONTACTORS
SAWS WITH LEESON MOTORS

FS-350 (ALL)	208/230	TE5.5	30AMP	10 AMP
	460	TE3.7	12AMP	6 AMP
FA-350 (ALL)	208	TE8	30AMP	10 AMP
	230	TE8	30AMP	10 AMP
	460	TE3.7	12AMP	6 AMP

SAWS WITH BALDOR MOTORS

FS-350 (ALL)	208/230	TE8	30AMP	10 AMP
	460	TE3.7	12AMP	6 AMP
FA-350 (ALL)	208	TE8	30AMP	10 AMP
	230	TE8	30AMP	10 AMP
	460	TE3.7	12AMP	6 AMP