

# How to use the glass microwave popcorn popper

Using the glass popcorn popper to pop non-microwave popcorn.

## Step-by-step guide

1. Fill the lid to the fill line.
2. Pour the kernels into the bottom of the popper, place the lid on top of the popper. Optional - Add desired amount of butter to the perforated lid and set the top of the popper to allow butter to melt on top of popcorn. **Note: The perforated lid must be placed on the popper even if not using it to melt butter.**
3. Not all microwaves work exactly the same, so play with the timing until you get it just right. Try setting the microwave between 2:30 and 3:00 minutes and listen to the pops. **DO NOT** use the popcorn button or setting on the microwave. It may take a while for things to get poppin'. Be patient and do not leave microwave unattended. When the popping slows down to about 2 seconds apart, stop the microwave to prevent burning. If no popping occurs within 2 minutes, turn OFF the microwave. Do not stop the microwave and start it again during the same batch.



## Related articles

- [How to use the glass microwave popcorn popper](#)